



[Click here to get the complete manual](#)

# MEGA 300-III

MECHATROPIA™



D A E W O O W H E E L L O A D E R

## Shop Manual

Printed in U.S.A.  
Copyright 1997

Serial Number 0001 and Up

June 1997  
2023-7105E

# TABLE OF CONTENTS

## **SAFETY**

To the Operator of a Daewoo Wheel Loader . . . . .	1-1
Basic Wheel Loader Operating Safety . . . . .	1-1
General Safety Essentials . . . . .	1-1
Locations of Safety Labels . . . . .	1-2
Summary of Safety Precautions for Lifting . . . . .	1-5
Operation . . . . .	1-7
Equipment . . . . .	1-10
Maintenance . . . . .	1-11
Shipping and Transportation . . . . .	1-13

## **SPECIFICATIONS**

Component Locations . . . . .	2-1
General Specifications . . . . .	2-2
Excavator Engine Specifications . . . . .	2-3
Engine Performance Curves . . . . .	2-4
Working Range and Dimensions . . . . .	2-5
Working Capacities . . . . .	2-7
Approximate Weight of Workload Materials . . . . .	2-8

## **INSPECTION, MAINTENANCE AND ADJUSTMENT**

Preventive Maintenance . . . . .	3-1
Safety Precautions . . . . .	3-1
Maintenance Intervals . . . . .	3-2
Table of Recommended Lubricants . . . . .	3-3
Inspection and Maintenance . . . . .	3-4
Daily or Every 10 Operating Hours . . . . .	3-7
Weekly or Every 50 Operating Hours . . . . .	3-10
Every 250 Operating Hours . . . . .	3-12
Every 500 Operating Hours . . . . .	3-13
Every 1,000 Operating Hours . . . . .	3-13
Every 1,500 Operating Hours . . . . .	3-18
Annually or Every 2,000 Operating Hours . . . . .	3-18
Severe Conditions Maintenance . . . . .	3-20
General Maintenance . . . . .	3-21
Check Hydraulic Pressures . . . . .	3-22
Tires and Wheels . . . . .	3-25
Electrical System . . . . .	3-26
Bolt Torque Chart . . . . .	3-27
Long Term Storage . . . . .	3-28

## **TORQUE CONVERTER AND TRANSMISSION**

Drive Train . . . . .	4-1
Transmission . . . . .	4-2
Transmission Troubleshooting . . . . .	4-5
Control Valve . . . . .	4-7
Second Gear Valve . . . . .	4-12
Transmission WG-180 Control Valve . . . . .	4-18
Transmission Disassembly . . . . .	4-21

Transmission Assembly . . . . .	4-42
Power Disengagement Gearbox . . . . .	4-82
Differential Type Output Gearing . . . . .	4-87
WK Torque Converter . . . . .	4-98
WK Converter Clutch Valve . . . . .	4-109
<b>POWER STEERING</b>	
Power Steering System . . . . .	5-1
Steering System Troubleshooting . . . . .	5-5
Steering Unit . . . . .	5-6
Priority Valve . . . . .	5-19
<b>AXLES</b>	
Front and Rear Axles . . . . .	6-1
Axle Troubleshooting . . . . .	6-2
Front Axle Housing . . . . .	6-3
Axle Differential . . . . .	6-4
Planetary Gear Set . . . . .	6-7
Parking Brake . . . . .	6-9
Rear Axle . . . . .	6-11
Brake System . . . . .	6-13
<b>HYDRAULIC SYSTEM</b>	
Hydraulic Circuits Description . . . . .	7-1
Hydraulic Pump . . . . .	7-3
Hydraulic Circuits and Components . . . . .	7-18
Manually Controlled Pilot Valve . . . . .	7-23
Automatic Bucket Return-to-Dig System . . . . .	7-24
Automatic Boom Kick-out System . . . . .	7-25
Automatic Boom Float System . . . . .	7-25
Hydraulic Cylinders . . . . .	7-27
Accumulator . . . . .	7-40
Hydraulic System Schematic . . . . .	7-45
<b>ENGINE</b>	
Engine Specifications (D2366T) . . . . .	8-1
Valve Adjustment Sequence . . . . .	8-2
Engine Cylinder Compression Test . . . . .	8-2
Wear Limits of Major Engine Components . . . . .	8-2
Engine Oil Pump Overhaul and Rebuilding . . . . .	8-7
Fuel Injection Pump Installation, Alignment and Timing . . . . .	8-9
Cylinder Head Bolt Torque Requirements . . . . .	8-11
<b>ELECTRICAL SYSTEM</b>	
Electrical Schematic . . . . .	9-1
24 Volt Operation . . . . .	9-1
Wiring Color Code for Electrical Schematic Diagrams . . . . .	9-1
Engine Start Circuit . . . . .	9-2
Engine Stop Motor . . . . .	9-4
Engine Intake Preheat Circuit . . . . .	9-6
Windshield Wiper Circuit . . . . .	9-8
Electrical System Schematic . . . . .	9-11
<b>INDEX</b> . . . . .	10-1