

[Click here to get the complete manual](#)

SERVICE MANUAL

Telehandlers
LMI060

Print No. 84121057



LM1060

TELEHANDLERS

Instructions manual for repairs

Document No. 84121057 (VII - 2008)



THIS WARNING SYMBOL HIGHLIGHTS IMPORTANT MESSAGES THAT AFFECT YOUR SAFETY.

Carefully read the safety instructions and follow the recommended precautions in order to avoid potential danger and safeguard your health and safety.

You will find this symbol in the text of this Manual with the following key words:

***CAUTION* - For warnings finalized at avoiding unsuitable repair operations and with potential consequences that involve the safety of the repairer.**

***DANGER* - When there are warnings that specifically signal potential danger for the safety of the operator or other people directly or indirectly involved.**

IMPORTANT WARNINGS

All the maintenance work and repairs described in this manual **must be performed exclusively by the manufacturer's support network**, rigorously respecting the instructions given and, where necessary, using the required specific equipment.

Any person performing service operations described in the manual and failing to abide strictly by the instructions becomes solely responsible for any consequential damage that could occur.

The Manufacturer and all organizations in the distribution chain associated with the Manufacturer, including national, regional and local dealers though not excluding others, decline all liability for damages attributable to abnormalities in the operation or response of parts and/or components not approved by the Manufacturer, used in the servicing and/or repair of a product built or marketed by the Manufacturer.

In any event, no warranty of any description is offered on or applicable to the product built or marketed by the Manufacturer, in respect of damages resulting from abnormal operation or response of parts and/or components not approved by the Manufacturer.

AVOID ACCIDENTS

Most accidents and injuries that occur in and around factories, on farms, in the home or on the roads, are caused by failure to follow some simple and fundamental rule regarding precautionary procedures and safety. Accordingly, IN THE MAJORITY OF CASES, ACCIDENTS CAN BE AVOIDED: it is sufficient simply to foresee the possible causes, and exercise the necessary caution and prudence.

Whatever the type of equipment, and however well designed and built, it is not possible to eliminate the risk of accident completely without adversely affecting certain essential features instrumental in providing reasonable levels of accessibility and ensuring smooth operation.

A careful and prudent operator is the best insurance against any accident.

The complete observance of this simple rule will of itself be sufficient in avoiding many serious accidents.

This rule is: never attempt any cleaning, lubrication or maintenance operation with the machine in motion.



CAUTION

Before commencing any kind of maintenance, adjustment or repair work on machines equipped with attachments operated hydraulically, mechanically or by wire ropes (such as front loaders, dozers, scrapers, etc.) make certain the attachment is lowered and resting on the ground.

If the attachment needs to be in the raised position in order to gain access to one part of the machine or another, it must be supported in the raised position by separate equipment, and not held with the machine controls.

MODEL DESIGNATIONS

The models making up the range of telescopic handlers (Telehandlers) described in this manual are identified in the text by reference to the maximum reach of the boom.

The vehicles listed below may not be available in all countries or on all markets. For up to date information on all machines, consult your authorized dealer.

Model	LM1060
Stabilizers	No
Engine	Turbocharged 88 kW
Maximum lifting height (m)	9750
Maximum capacity (kg) at 500 mm from fork rail	6000
Capacity at maximum height (kg)	3000
Extension at max. height (mm)	200
Max. longitudinal extension (mm)	5850
Capacity at maximum reach (kg)	1800
Weight (kg)	12300
Length (mm)	7533

Workshop manual

LM1060

TELESCOPIC HANDLER

GENERAL LIST OF CONTENTS

SECTION 00 - GENERAL

Description	Page
General instructions	1
Safety rules	3
Product identification	6
Environmental considerations	9
Maintenance techniques	10

SECTION 10 - ENGINE

Description	Page
Main engine specifications	3
General engine specifications	4
General engine specifications F4GE9484J*J600	6
Removal and installation of engine and radiator	11
Troubleshooting	23
Tightening torques	36
Special tools	37

SECTION 21 - POWERSHIFT GEARBOX

Description	Page
Transmission assembly	5
Drop box assembly	7
Operation of gearbox	8
Diagrams: operation of transmission and circulation of hydraulic oil	15
Operation of modulating valve	31
Torque converter hydraulic circuit	34
Troubleshooting guide	35
Troubleshooting procedures	35
Troubleshooting	37
Pressure tests on clutch and high pressure circuit	38
Pressure tests on torque converter and cooler circuit	39
Test points	40
Assembly instructions	42
Transmission overhaul	45
Special tools	104

SECTION 25 - FRONT AXLE

Description	Page
Technical data	1
Description	2
Operation	3
Troubleshooting	4
Wheel toe-in check	5
Component overhaul	5
Front axle removal procedure	6
Front axle overhaul	7
Axle drive pinion bearing adjustment	52
How to install and adjust the axle drive pinion	54
Front drive shaft	57

SECTION 27 - REAR AXLE

Description	Page
Technical data	1
Description	2
Functional diagram	3
Component overhaul	5
Rear axle removal procedure	5
Overhaul	6
Special tools	7

SECTION 33 - BRAKING SYSTEM

Description	Page
Service brakes	2
Parking brake	3
Brake disc adjustment	6
Troubleshooting	7
Brakes disassembly	8

SECTION 35 - HYDRAULIC SYSTEM

Description	Page
Technical data	2
Description and operation	3
Steering system hydraulic circuit	3
Steering valve	4
Telescopic boom hydraulic circuit	6
Component operation	9
Front loader controls/operation	12
Power steering (OSPQ)	16
Telescopic boom distributor	17
Chassis frame levelling control valve	21
Cylinders	22
Boom	28

SECTION 55 - ELECTRICAL SYSTEM

Description	Page
Chapter 1 - Electrical system - general	
Electrical equipment specifications	1
Electrical system and fuses	2
Controls and instruments	6
Using the tip-over prevention system	16
Bulb replacement	23
Protecting the electrical systems during charging or welding	26
Starting the machine using jump leads	27
Temporary wiring repairs	28
Electrical system - general fault finding	30
Special tools	31
Chapter 2 - Circuit diagrams	
List of connectors	34
List of components	35
How to use the circuit diagrams	36
Diagram 1: Starting/recharge/warning lights/indicators	38
Diagram 2: Transmission	40
Diagram 3: Wheel alignment/solenoid valves/brake system	42
Diagram 4: Boom control	44
Diagram 5: Levelling chassis frame / parking brake device	46
Diagram 6: Lights/windscreen wiper	48
Diagram 7: Work lights/beacon	50
Diagram 8: Tip-over prevention system/roof wiper	52
Diagram 9: Heater, radio/trailer socket/interior light	54
Diagram 10: Air-conditioning system	56