



# Service Manual

**802.7** *Plus*

**802.7** *Super*

**803** *Plus*

**803** *Super*

**804** *Plus*

**804** *Super*

Published by the  
TECHNICAL PUBLICATIONS DEPARTMENT  
of  
JCB COMPACT PRODUCTS LTD;  
Harewood Estate  
Leek Road, Cheadle  
Stoke-on Trent  
Staffordshire, England  
ST10 2JU  
Tel: 01538 757500, Fax: 01538 757590  
Publication No. 9803/3145 Issue 3

General Information	1
Care & Safety	2
Routine Maintenance	3
Optional Equipment	A
Body & Framework	B
Electrics	C
Controls	D
Hydraulics	E
Gearboxes	F
Track & Running Gear	J
Engine	L

## Introduction

This publication is designed for the benefit of JCB Distributor Service Engineers who are receiving, or have received, training by JCB Technical Training Department.

It is assumed that these personnel have a sound knowledge of workshop practice, safety procedures and general techniques associated with the maintenance and repair of hydraulic earthmoving equipment. Therefore, these basic subjects generally are omitted from this manual, the intention being to convey only more specialised information concerning particular aspects of a machine or component.

For example, renewal of oil seals, gaskets etc., and any component showing obvious signs of wear or damage is expected as a matter of course and, therefore, information of this nature is included only in the context of specialised procedures or where a range of wear tolerances is required. Similarly, it is expected that components will be cleaned and lubricated where appropriate, also that any opened hose or pipe connections will be blanked to prevent excessive loss of hydraulic fluid and ingress of dirt. Finally, please remember above all **SAFETY MUST COME FIRST!**

The manual is compiled in sections, the first three are numbered and contain information as follows:

**1** = **General Information** - includes torque settings and service tools  
**2** = **Care & Safety** - includes warnings and cautions pertinent to aspects of workshop procedures etc.  
**3** = **Routine Maintenance** - includes service schedules and recommended lubricants for the machine.

The remaining sections are alphabetically coded and deal with Dismantling, Overhaul etc. of specific components, for example:

**A** = **Optional Equipment**  
**B** = **Body & Framework** ... etc.

The page numbering in each alphabetically coded section may not be continuous. This allows for the insertion of new items in later issues of the manual.

Section contents, technical data, circuit descriptions, operation descriptions etc. are inserted at the beginning of each alphabetically coded section.

All sections are listed on the front cover; tabbed divider cards align directly with individual sections on the front cover for rapid reference.

Illustrations which show a dismantled component are numbered as a guide to the dismantling sequence, which generally can be reversed for assembly.

Torque settings are given as a 'mean' figure which may be varied by plus or minus 3%. Torque figures indicated are for dry threads, hence for lubricated threads may be reduced by one third.

'Left Hand' and 'Right Hand' are as viewed from the rear of the machine.

References to alternative servicing intervals are to be treated on a 'whichever occurs first' basis.

<b>Contents</b>	<b>Page No.</b>
Identification .....	1 - 1
Storing your machine .....	2 - 1
 <b>Operation</b>	
Introduction .....	B1
Before entering the cab .....	B2 - B3
Entering/exiting the cab .....	B4 - B5
Cab .....	B6 - B7
Opening the windscreen .....	B8
Opening the side window .....	B9
Heater controls .....	B10 - B11
Seat .....	B12
Seat belt (when fitted) .....	B13
Engine and track controls	
Switches and instruments .....	B14 - B15
Track controls .....	B16 - B17
Engine controls .....	B19
Switches .....	B20 - B21
Instruments .....	B24 - B25
Dozer controls .....	B26 - B27
Excavator controls .....	B28 - B23
Slew cab .....	B30
Swing boom .....	B31
Boom swing stop .....	B32-B33
Raise / Lower boom .....	B34-B35
Dipper .....	B36
Bucket .....	B37
Refuelling the machine .....	B39
Before starting the engine .....	B40 - B41
Starting the engine .....	B42 - B43
Jump starting the engine .....	B44 - B46
Cold climate warm up .....	B47
Operating in high / low temperatures .....	B48
Stopping and parking the machine .....	B50 - B51
Preparing for road / site travel .....	B52 - B53
Getting the machine moving .....	B54 - B55
Working with the dozer .....	B56 - B57
Working with the excavator .....	B58 - B43
Installing a bucket - non Quickhitch models .....	B58 - B59
Replacing bucket teeth .....	B59
Removing a bucket .....	B37
Bucket selection .....	B60
Removing a bucket - non Quickhitch models .....	B61
Installing a bucket on a Quickhitch .....	B62 - B63
Removing a bucket from a Quickhitch .....	B64 - B65
Working on a slope .....	B66 - B67
Digging .....	B68 - B69
Moving the machine while digging on the level .....	B70
Digging near walls .....	B71
Lifting .....	B72
Safe working loads .....	B73
Using the attachments and site safety .....	B74 - B77
Single/double acting circuits .....	B78 - B79
Removing a Quickhitch Rockbreaker .....	B80 - B83
Using hand held tools .....	B84 - B85
Moving a disabled machine .....	B86 - B87
Transporting the machine .....	B88 - B89
Securing for Transport .....	B90 - B91