

8025ZTS, 8026CTS, JS30, 8029CTS, 8030ZTS, 8035ZTS

Service Manual - 8025ZTS, 8026CTS, JS30, 8029CTS, 8030ZTS, 8035ZTS

[Section 1 - General Information](#)

[Section 2 - Care and Safety](#)

[Section 3 - Maintenance](#)

[Section A - Attachments](#)

[Section B - Body and Framework](#)

[Section C - Electrics](#)


[Section D - Controls](#)

[Section E - Hydraulics](#)

[Section F - Gearboxes](#)

[Section J - Track and Running Gear](#)

[Section K - Engine](#)



Publication No.
9803/9410-08



Copyright © 2007 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

General Information

Service Manual - 8025ZTS, 8026CTS, JS30, 8029CTS, 8030ZTS, 8035ZTS

[Section 1 - General Information](#)

[Section 2 - Care and Safety](#)

[Section 3 - Maintenance](#)

[Section A - Attachments](#)

[Section B - Body and Framework](#)

[Section C - Electrics](#)


[Section D - Controls](#)

[Section E - Hydraulics](#)

[Section F - Gearboxes](#)

[Section J - Track and Running Gear](#)

[Section K - Engine](#)



Publication No.
9803/9410-08



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.



Section 1 - General Information

Contents	Page No.
Introduction	
About this Manual	3-1
Machine Model and Serial Number	3-1
Using the Service Manual	3-1
Section Numbering	3-1
Left Side, Right Side	3-2
Cross References	3-2
Identifying Your Machine	
Identification Plates	3-3
Data Plate	3-3
Typical Product Identification Number (VIN)	3-3
Typical Product Identification Number (PIN)	3-3
Typical Engine Identification Number	3-3
ROPS, TOPS and FOGS	3-4
Standard Torque Settings	
Zinc Plated Fasteners and Dacromet Fasteners	3-5
Introduction	3-5
Bolts and Screws	3-5
Hydraulic Connections	3-9
'O' Ring Face Seal System	3-9
'Torque Stop' Hose System	3-12
Service Tools	
Numerical List	3-13
Tool Detail Reference	3-16
Section B - Frame and Bodywork	3-16
Section C - Electrics	3-20
Section E - Hydraulics	3-21
Section K - Engine	3-27
Service Consumables	
Sealing and Retaining Compounds	3-29
Terms and Definitions	
Colour Coding	3-31
Hydraulic Schematic Colour Codes	3-31

Introduction

About this Manual

Machine Model and Serial Number

This manual provides information for the following model(s) in the JCB machine range:

JCB 8025ZTS from serial number 1226500
JCB 8026CTS from serial number 1779000
JCB 8029CTS from serial number 2314949
JCB 8030ZTS from serial number 1228500
JCB 8035ZTS from serial number 1230500
JS30 from serial number 2305191 to 2307191

Using the Service Manual

T11-004

This publication is designed for the benefit of JCB Distributor Service Engineers who are receiving, or have received, training by JCB Technical Training Department.

These personnel should have a sound knowledge of workshop practice, safety procedures, and general techniques associated with the maintenance and repair of hydraulic earthmoving equipment.

The illustrations in this publication are for guidance only. Where the machines differ, the text and/or the illustration will specify.

General warnings in Section 2 are repeated throughout the manual, as well as specific warnings. Read all safety statements regularly, so you do not forget them.

Renewal of oil seals, gaskets, etc., and any component showing obvious signs of wear or damage is expected as a matter of course. It is expected that components will be cleaned and lubricated where appropriate, and that any opened hose or pipe connections will be blanked to prevent excessive loss of hydraulic fluid and ingress of dirt.

Where a torque setting is given as a single figure it may be varied by plus or minus 3%. Torque figures indicated are for dry threads, hence for lubricated threads may be reduced by one third.

The manufacturer's policy is one of continuous improvement. The right to change the specification of the machine without notice is reserved. No responsibility will be accepted for discrepancies which may occur between specifications of the machine and the descriptions contained in this publication.

Finally, please remember above all else safety must come first!

Section Numbering

T11-005

The manual is compiled in sections, the first three are numbered and contain information as follows:

- 1 General Information - includes torque settings and service tools.
- 2 Care and Safety - includes warnings and cautions pertinent to aspects of workshop procedures etc.
- 3 Maintenance - includes service schedules and recommended lubricants for all the machine.

The remaining sections are alphabetically coded and deal with Dismantling, Overhaul etc. of specific components, for example:

- A Attachments
- B Body and Framework, etc.

Section contents, technical data, circuit descriptions, operation descriptions etc. are inserted at the beginning of each alphabetically coded section.