# 

## WORKSHOP MANUAL TRACTOR

**B3200** 

Kubota

### TO THE READER

This Workshop Manual has been prepared to provide servicing personnel with information on the mechanism, service and maintenance of B3200. It is divided into three parts, "General", "Mechanism" and "Servicing".

#### ■ General

Information on the tractor identification, the general precautions, maintenance check list, check and maintenance and special tools are described.

#### ■ Mechanism

Information on the construction and function are included. This part should be understood before proceeding with troubleshooting, disassembling and servicing.

Refer to Diesel Engine / Tractor Mechanism Workshop Manual (Code No. 9Y021-01876 / 9Y021-18201) for the one which has not been described to this workshop manual.

#### Servicing

Information on the troubleshooting, servicing specification lists, tightening torque, checking and adjusting, disassembling and assembling, and servicing which cover procedures, precautions, factory specifications and allowable limits.

All information illustrations and specifications contained in this manual are based on the latest product information available at the time of publication.

The right is reserved to make changes in all information at any time without notice.

Due to covering many models of this manual, information or picture being used, have not been specified as one model.

October 2008

© KUBOTA Corporation 2008