WORKSHOP MANUAL

F2260,F2560(E),F3060,F3560

Kubota

TO THE READER

This Workshop Manual has been prepared to provide servicing personnel with information on the mechanism, service and maintenance of KUBOTA F2260, F2560 (E), F3060 and F3560. It is divided into two parts, "Mechanism" and "Servicing" for each section.

■ Mechanism

Information on the construction and function are included. This part should be understood before proceeding with troubleshooting, disassembling and servicing.

■ Servicing

Under the heading "General" section comes general precautions, check and maintenance and special tools. Other section, there are troubleshooting, servicing specification lists, checking and adjusting, disassembling and assembling, and servicing which cover procedures, precautions, factory specifications and allowable limits.

All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication.

The right is reserved to make changes in all information at any time without notice.

Note

The following models are sold in the countries shown in the table below.

MODEL	U.S.A	Canada	Oceania	Europe
F2260		0	0	0
F2560	0	0	0	0
F2560E	0	0	0	0
F3060	0	0	0	0
F3560		0	0	0

February 2002

© KUBOTA Corporation 2002