WORKSHOP MANUAL

F2690E,F2690,F3990,RCK60P-F39, RCK60R-F36,RCK72P-F39, RCK72R-F36

Kubota

TO THE READER

This Workshop Manual tells the servicing personnel about the mechanism, servicing and maintenance of the F2690E, F2690 and F3990, KUBOTA Mower RCK60P-F39, RCK60R-F36, RCK72P-F39 and RCK72R-F36. It contains 4 parts: "Information", "General", "Mechanism" and "Servicing".

■ Information

This section primarily contains information below.

- Safety First
- · Safety Decal
- · Specification
- Dimension

■ General

This section primarily contains information below.

- · Engine Identification
- · Model Identification
- · General Precautions
- Maintenance Check List
- · Check and Maintenance
- · Special Tools

Mechanism

This section contains information on the structure and the function of the unit. Before you continue with the subsequent sections, make sure that you read this section.

Refer to the latest version of Workshop Manual (Code No. 9Y021-01870) for the diesel engine / tractor mechanism that this workshop manual does not include.

Servicing

This section primarily contains information below.

- Troubleshooting
- · Servicing Specifications
- · Tightening Torques
- · Checking, Disassembling and Servicing

Regarding the servicing of electric control system of V1505-T-E4 (F3990), refer to "Diagnosis Manual V1505-T-E4 (9Y120-02490)".

Regarding the servicing of Diesel Particulate Filter (DPF), refer to "DIESEL PARTICULATE FILTER HANDLING MANUAL" (9Y111-08130).

All illustrations, photographs and specifications contained in this manual are of the newest information available at the time of publication.

KUBOTA reserves the right to change all information at any time without notice.

Since this manual includes many models, information or illustrations and photographs can show more than one model.

August, 2013

© KUBOTA Corporation 2013