

WSM

WORKSHOP MANUAL
KUBOTA WHEEL LOADER

R320S, R320S(B)

Kubota

CONTENTS

TO THE READER	
TO THE READER	
INFORMATION	
CONTENTS	
INFORMATION	
1. SAFETY FIRST	I-1
2. WORK SAFETY.....	I-2
3. SAFETY DECALS	I-6
4. TABLE OF MAIN SPECIFICATIONS	I-10
5. DIMENSIONS	I-12
GENERAL	
CONTENTS	
GENERAL	
1. MACHINE IDENTIFICATION	G-1
2. ENGINE IDENTIFICATION.....	G-2
3. GENERAL PRECAUTIONS.....	G-3
4. HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING.....	G-7
5. TYPES OF OIL	G-11
6. TIGHTENING TORQUES.....	G-12
7. MAINTENANCE CHECK LIST	G-17
ENGINE	
CONTENTS	
GENERAL	
1. ENGINE	1-G1
2. SPECIAL TOOLS	1-G4
SERVICING	
1. TROUBLESHOOTING.....	1-S1
2. SERVICE STANDARD	1-S6
3. TIGHTENING TORQUES.....	1-S11
4. DISASSEMBLY, REASSEMBLY AND MAINTENANCE.....	1-S13
5. RADIATOR	1-S70
6. ACCELERATOR.....	1-S71
7. FUEL HOSES	1-S73
8. MUFFLER.....	1-S74
9. AIR CLEANER.....	1-S75
10. ENGINE MOUNTS	1-S76
HYDRAULIC SYSTEM	
CONTENTS	
MECHANISM	
1. HYDRAULIC CIRCUIT	2-M1
2. HYDRAULIC EQUIPMENT SCHEMATIC.....	2-M2
3. OIL FLOW.....	2-M3
4. LST PUMP SPECIFICATIONS.....	2-M5
5. LST MOTOR SPECIFICATIONS.....	2-M6
SERVICING	
1. LST PUMP	2-S1
2. LST MOTOR.....	2-S22
3. HL CONTROL VALVE	2-S30
4. FILTER FLANGE	2-S32
5. OIL TANK	2-S33
6. ROUTING OF HYDRAULIC HOSES.....	2-S34
7. MEASUREMENT OF HYDRAULIC DEVICE PERFORMANCE	2-S40
8. TROUBLESHOOTING (HYDRAULIC SYSTEM).....	2-S47
9. BREAKDOWN TOWING PROCEDURE	2-S51
POWER TRAIN	
CONTENTS	
MECHANISM	
1. DRIVETRAIN	3-M1
SERVICING	
1. TRANSMISSION.....	3-S1
2. FRONT AXLE AND REAR AXLE DIFFERENTIAL CASES	3-S7
BRAKES	
CONTENTS	
MECHANISM	
1. BRAKE SYSTEM	4-M1
SERVICING	
1. BRAKE COMPONENTS	4-S1
2. MASTER CYLINDER.....	4-S5
3. NEGATIVE BRAKE.....	4-S6
4. BRAKE LINE AIR BLEEDING PROCEDURE	4-S12
5. BRAKE PERFORMANCE MEASUREMENTS.....	4-S13
6. TROUBLESHOOTING (BRAKE SYSTEM).....	4-S15
STEERING	
CONTENTS	
MECHANISM	
1. STEERING SYSTEM.....	5-M1
2. STEERING CONTROLLER SPECIFICATIONS	5-M3
3. STEERING CYLINDER SPECIFICATIONS	5-M4
SERVICING	
1. STEERING WHEEL UNIT	5-S1
2. STEERING CONTROLLER.....	5-S2
3. STEERING CYLINDER	5-S22
4. STEERING PERFORMANCE MEASUREMENT	5-S28
5. TROUBLESHOOTING (STEERING).....	5-S29
FRONT LOADER	
CONTENTS	
MECHANISM	
1. FRONT LOADER.....	6-M1
SERVICING	
1. FRONT.....	6-S1
2. IMPLEMENT CONTROL LEVER.....	6-S3
3. CONTROL VALVE.....	6-S5
4. MEASURING FRONT PERFORMANCE	6-S15
5. TROUBLESHOOTING (FRONT).....	6-S20