

[CLICK HERE FOR
TABLE OF
CONTENTS](#)



TR60 Off-Highway Truck Maintenance Manual



[CLICK HERE TO RETURN TO
MAIN LIBRARY INDEX](#)

TECHNICAL PUBLICATIONS DEPARTMENT
TEREX EQUIPMENT LIMITED,
MOTHERWELL, SCOTLAND, ML1 5RY
REF. NO. SM750/782

TABLE OF CONTENTS

Section No.	Description	SM No.
000 0000	GENERAL INFORMATION TR60 Off-Highway Truck	1566
100 0010 0010	CHASSIS Chassis, Hood and Fenders - Pre September 1999 Production Chassis, Hood and Fenders - From September 1999 Production	1570 1904
110 0030 0050 0130	ENGINE Engine and Mounting Air Cleaner Power Takeoff	1571 1572 1573 Rev 1
120 0010 0010 0070 0070 0090 0100 0100	TRANSMISSION Transmission and Mounting - Pre July 1999 Production Transmission and Mounting - From July 1999 Production Commercial Electronic Control (CEC) Shift System Commercial Electronic Control 2 (CEC2) Power Takeoff Transmission Oil Filter - Pre January 2000 Production Transmission Oil Filter - From January 2000 Production	1574 1905 1575 Rev 2 2128 1178 1576 1906
130 0010 0010 0020 0020	DRIVELINE Front Driveline - Pre June 1998 Production Front Driveline - From June 1998 Production Rear Driveline - Pre June 1998 Production Rear Driveline - From June 1998 Production	1180 1577 1181 1578
140 0040	FRONT AXLE Wheel, Rim and Tyre	1579
160 0020 0030 0050	REAR AXLE Differential Axle Group Wheel, Rim and Tyre	1580 Rev 1 1184 1582
165 0020 0030	BRAKE PARTS Brake Parts - Front Axle Brake Parts - Rear Axle	1186 1583
180 0030 0050	SUSPENSION SYSTEM Ride Cylinder - Front Ride Cylinder - Rear	1584 1189
190 0000 0270	CIRCUIT DIAGRAMS Circuit Diagrams Switches and Sensors	1585 1586 Rev 1
200 0010 0040 0051	FUEL SYSTEM Fuel Tank and Mounting Fuel Lines Electronic Foot Pedal	1587 1195 1196
210 0000 0040 0050 0060	COOLING SYSTEM Cooling System Radiator, Header Tank and Mounting Disc Brake Oil Cooler Transmission Oil Cooler	1197 1588 Rev 1 1589 1590

TABLE OF CONTENTS

Section No.	Description	SM No.
220	STEERING SYSTEM	
0000	Steering System Schematic	1591
0040	Steering and Brake Control Tank	1592
0050	Steering Pump	1204
0080	Accumulator	1205
0090	Steering Valve	1206 Rev 1
0110	Double Relief Valve	1208
0120	Steering Cylinder and Linkage - Pre October 1999 Production	1207 Rev 1
0120	Steering Cylinder and Linkage - From October 1999 Production	1908
0130	Accumulator Valve	1209
0150	Steering Filter	1593
230	BODY SYSTEM	
0000	Body System Schematic	1594 Rev 2
0040	Body and Disc Brake Cooling Tank	1595
0050	Tandem Pump	1213
0060	Body Control Valve	1596 Rev 1
0081	Body Control Joystick	1597
0090	Kick-over Valve	1218
0120	Relief Valve	1598
0121	Pilot Supply Valve	1599
0130	Body Cylinder	1221
250	BRAKING SYSTEM	
0000	Braking System Schematic	1222 Rev 1
0050	Brake Manifold Valve	1223
0060	Accumulator	1600
0070	Treadle Valve	1225 Rev 1
0090	Directional Control Valve	1226
0100	Monoblock Brake Valve	1227 Rev 2
0110	Pressure Reducing Valve (Optional)	1820
0130	Retarder Control Valve	1601 Rev 1
0140	Shuttle Valve	1229
260	OPERATORS COMPARTMENT	
0010	Cab and Mounting	1602 Rev 1
0090	Driver Seat and Mounting	1901
0110	Passenger Seat and Mounting - Pre January 2000 Production	1603
0110	Passenger Seat and Mounting - From January 2000 Production	1902
0130	Air Conditioning and Mounting	1620 Rev 1
270	BODY	
0010	Body and Mounting	1604
300	MISCELLANEOUS	
0020	Lubrication System	1605 Rev 1
0070	Service Tools	1237 Rev 1
0080	Standard Bolt and Nut Torque Specifications	1238
0090	Unit Storage	1239

* * * *