



Service Manual

Serial number range

GTH-4016 SR

From serial n.: 20094

GTH-4018 SR

From serial n.: 19785

Part. No. 57.4400.9203
Rev A
March 2010

Table of Contents

Introduction

Important Information.....	<i>ii</i>
Machine Identification.....	<i>iii</i>

Section 1

Safety Rules

Personal Safety Rules	<i>v</i>
-----------------------------	----------

Section 2

Rev

Specifications

A	Operation Description	1
	Performance Specifications.....	8
	Hydraulic Specifications.....	9
	Perkins 1104C-44T Engine.....	10
	Carraro 2632M FR Drive Axle	10
	Hydraulic Hose and Fitting Torque Specifications	11
	Metric Fasteners Torque Charts.....	12

Section 3

Rev

Scheduled Maintenance Procedures

A	Introduction.....	13
	Pre-delivery Preparation Report	15
	Maintenance Inspection Report.....	17
A	Checklist A Procedures	
	A-1 Inspect the Manuals and Decals.....	18
	A-2 Perform Pre-operation Inspection	19
	A-3 Perform Function Test.....	19
	A-4 Machine Greasing.....	20
	A-5 Epicyclic Reduction Gears Oil Level	21
	A-6 Axles Oil Level	21
	A-7 Tyre Inflation	22
	A-8 Engine Oil Level.....	22
	A-9 Engine Cooling System.....	23
	A-10 Lighting System.....	23
	A-11 Clean Engine Air Filter	24
	A-12 Safety Devices	24

