

TABLE OF CONTENTS

Electrical Circuits

DD80, DD80L - Canopy Model3

DD80, DD80L - Cabin Model4

Hydraulic Circuits

DD80, DD80L6

TABLE OF CONTENTS

Electrical Circuits

DH 030.....	4
DH 050.....	5
DH 050.....	6
DH 130.....	7
DH 130 (S/N 0483 and Up).....	8
DH 130W	9
DH 130-2	10
DH 170.....	11
DH 180 / DH 220	12
DH 200W	13
DH 220LC	14
DH 280LC	15
DH 320LC	16
DH 450.....	17

Hydraulic Circuits

DH 030.....	19
DH 050 (S/N 0001 thru 5600)	20
DH 050 (S/N 5601 thru 5999).....	21
DH 050 (S/N 6001 and Up).....	22
DH 130.....	23
DH 130W	24
DH 130W	25
DH 130-2	26
DH 170.....	27
DH 180 / DH 200	28
DH 200W	29
DH 200W	30
DH 220 (S/N 0001 thru 1779)	31
DH 220 (S/N 1780 and Up).....	32
DH 280.....	33
DH 320.....	34

TABLE OF CONTENTS

Electrical Circuits

Solar 070-III 4
Solar 130LC-III..... 5
Solar 130W-III..... 6
Solar 170LC-III..... 7
Solar 170W-III..... 8
Solar 170W-III..... 9
Solar 200W-III..... 10
Solar 220LC-III..... 11
Solar 280LC-III..... 12
Solar 330LC-III..... 13
Solar 400LC-III..... 14
Solar 450-III 15

Hydraulic Circuits

Solar 070-III 17
Solar 070-III (with Dozer)..... 18
Solar 130LC-III..... 19
Solar 130LC-III..... 20
Solar 130LC-III..... 21
Solar 130W-III (S/N 0001 thru 1720) with DX22 Control Valve..... 22
Solar 130W-III (S/N 0001 thru 0097) 23
Solar 130W-III (0098 and Up)..... 24
Solar 170LC-III..... 25
Solar 170W-III (Standard)..... 26
Solar 170W-III (Standard)..... 27
Solar 170W-III (Optional) 28
Solar 200W-III (with Standard Boom) (S/N 0001 thru 0448) 29
Solar 200W-III (with Standard Boom) (S/N 0449 and Up)..... 30
Solar 200W-III (with Articulated Boom) (S/N 0001 thru 0448)..... 31
Solar 200W-III (with Articulated Boom) (S/N 0449 and Up) 32
Solar 220LC-III (S/N 0216 thru 0360) 33
Solar 220LC-III (S/N 0361 thru 1420)..... 34

TABLE OF CONTENTS

Electrical Circuits

Solar 010	5
Solar 015	6
Solar 015 PLUS (S/N 1001 thru 1157, 20001 thru 20065)	7
Solar 015 PLUS (S/N 20066 thru 30000)	8
Solar 015 PLUS / Solar 018-VT (S/N 30001 and Up).....	9
Solar 030 / 035	10
Solar 030Plus / 035	11
Solar 055	12
Solar 055-V PLUS (S/N 1001 thru 1200, 31201 thru 32135)	13
Solar 055-V PLUS (S/N 32136 and Up)	14
Solar 055W-V PLUS.....	15
Solar 075-V (S/N 1001 thru 1153).....	16
Solar 075-V (S/N 1154 thru 1645).....	17
Solar 75-V (S/N 1646 and Up).....	18
Solar 130LC-V	19
Solar 130W-V	20
Solar 140LC-V (S/N 1001 thru 1094)	21
Solar 140LC-V (S/N 1095 and Up)	22
Solar 140W-V / 160W-V	23
Solar 170LC-V	24
Solar 170W-V	25
Solar 175LC-V	26
Solar 180W-V (S/N 1001 thru 1099).....	27
Solar 180W-V (S/N 1100 and Up)	28
Solar 200W-V	29
Solar 210W-V (S/N 1001 thru 1409).....	30
Solar 210W-V (S/N 1410 and Up)	31
Solar 220LC-V (S/N 1001 thru 2441)	32
Solar 220LC-V (S/N 2442 and Up)	33
Solar 220LL	34
Solar 225LC-V (S/N 1001 thru 1299)	35
Solar 225LC-V (S/N 1300 and Up)	36

TABLE OF CONTENTS

Electrical Circuits

DX015 / DX018.....	4
DX027Z / DX030Z	5
DX035Z.....	6
DX055.....	7
DX055W	8
DX055W (Yanmar TNV Engine)	9
DX060R	10
DX060R (Yanmar TNV Engine)	11
DX080R	12
DX080R (Yanmar TNV Engine)	13
DX140LC	14
DX140W / DX160W	15
DX180LC	16
DX190W	17
DX210W	18
DX225LC (S/N 5001 thru 5433)	19
DX225LC (S/N 5434 and Up)	20
DX225NLC.....	21
DX255LC	22
DX300LL.....	23
DX300LC / DX340LC.....	24
DX420LC	25
DX480LC / DX520LC.....	26

Hydraulic Circuits

DX015.....	28
DX018.....	29
DX027Z.....	30
DX030Z.....	31
DX035Z.....	32
DX055.....	33
DX055W	34

TABLE OF CONTENTS

Electrical Circuits

Mega 130.....	4
Mega 160 (S/N 0001 thru 1020)	5
Mega 160 (w/Aux. Steering) (S/N 0001 thru 1020).....	6
Mega 160 (S/N 1021 and Up).....	7
Mega 200-III.....	8
Mega 200-V (Tier I) (S/N 1001 thru 2000).....	9
Mega 200-V (Tier II) (S/N 2001 thru 3000).....	10
Mega 200-V (S/N 3001 and Up)	11
Mega 250-III.....	12
Mega 250-V (Tier I).....	13
Mega 250-V (Tier II).....	14
Mega 300-III.....	15
Mega 300-V	16
Mega 400-III.....	17
Mega 400-III PLUS	18
Mega 400-V	19
Mega 500-V (Tier II).....	20

Hydraulic Circuits

Mega 130.....	22
Mega 160 (Main) (S/N 0001 thru 1020)	23
Mega 160 (Option) (S/N 0001 thru 1020)	24
Mega 160 (Main) (S/N 1021 and Up).....	25
Mega 160 (with Aux. Steering) (S/N 1021 and Up)	26
Mega 200-III.....	27
Mega 200-V (Standard) (S/N 1001 thru 3000)	28
Mega 200-V (Option) (S/N 1001 thru 3000)	29
Mega 200-V (Option) (S/N 3001 and Up)	30
Mega 250-III.....	31
Mega 250-V (Tier I) S/N 1001 thru 2000	32
Mega 250-V (Tier II) S/N 2001 thru 3000	33
Mega 250-V (Tier I) S/N 3001 thru 4000	34

TABLE OF CONTENTS

Electrical Circuits

DL160	3
DL200 (S/N 5001 and Up)	4
DL200 TONY (S/N 5001 and Up)	5
DL250 (S/N 5001 and Up)	6
DL300 (S/N 5001 and Up)	7
DL400 (S/N 5001 and Up)	8
DL450	9
DL500 (S/N 5001 and Up)	10

Hydraulic Circuits

DL160	12
DL200 (S/N 5001 and Up)	13
DL200 TONY (S/N 5001 and Up)	14
DL250 (S/N 5001 and Up)	15
DL250 (S/N 5001 and Up)	16
DL300 (S/N 5001 and Up)	17
DL400 (S/N 5001 and Up)	18
DL450	19
DL500 (S/N 5001 and Up)	20