

[Click here to get the complete manual](#)

DX55

Shop Manual

K1038080E

Serial Number 50001 and Up

DOOSAN reserves the right to improve its products continuously, delivering the best possible product to the marketplace. These improvements can be implemented at any time with no obligation to change materials previously sold. It is recommended that consumers periodically contact their distributors for most recent documentation on purchased equipment.

This documentation may include attachments and optional equipment not available in your machine's package. Please call your distributor for additional items that you may require.

Illustrations used throughout this manual are used only as a representation of the actual piece of equipment, and may vary from the actual item.

Table of Contents

Safety

| | |
|-----------------------------|----------|
| Track Excavator Safety..... | SP001478 |
|-----------------------------|----------|

Specifications

| | |
|------------------------------|----------|
| Specification for DX55 | SP001479 |
|------------------------------|----------|

General Maintenance

| | |
|-------------------------------------|----------|
| General Maintenance Procedures..... | SP000016 |
| Standard Torques..... | SP000813 |

Upper Structure

| | |
|--------------------|----------|
| Cabin | SP001480 |
| Swing Bearing..... | SP001551 |

Lower Structure and Chassis

| | |
|----------------------|----------|
| Track Assembly | SP001481 |
|----------------------|----------|

Engine and Drive Train

| | |
|---------------------------------|----------|
| Engine..... | SP001434 |
| Drive Coupling (Main Pump)..... | SP001482 |

Hydraulics

| | |
|----------------------------|----------|
| Accumulator..... | SP000028 |
| Center Joint (Swivel)..... | SP001483 |
| Cylinders..... | SP001484 |
| Swing Motor..... | SP001485 |
| Travel Motor..... | SP001486 |
| Main Control Valve | SP001487 |
| Main Pump..... | SP001488 |

| | |
|--|----------|
| Remote Control Valve (Work Lever / Joystick) | SP001489 |
| Dozer Valve | SP001490 |
| Pedal Valve..... | SP001491 |
| Hydraulic Schematic (DX55)..... | SP001492 |

Electrical System

| | |
|-----------------------------------|----------|
| Electrical System | SP001493 |
| Electrical Schematic (DX55) | SP001494 |

Attachments

| | |
|-------------------|----------|
| Boom and Arm..... | SP001495 |
| Bucket..... | SP001496 |