

T140




Bobcat®

Service Manual

S/N 527111001 & Above

S/N 527211001 & Above



Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Bobcat Company or the products of either.

**EQUIPPED WITH
BOBCAT INTERLOCK
CONTROL SYSTEM (BICS™)**



Printed in U.S.A.

ALPHABETICAL INDEX

ADVANCED CONTROL SYSTEM (ACS)		HYDRAULIC FLUID RESERVOIR	20-01
SELECTRABLE HAND/FOOT CONTROL.....	60-01	HYDRAULIC/HYDROSTATIC FILTER	20-01
ALTERNATOR	60-01	HYDRAULIC FLUID SPECIFICATIONS.....	SPEC-01
AIR CLEANER SERVICE	10-01, 70-01	HYDRAULIC/HYDROSTATIC SYSTEM.....	10-01
		HYDRAULIC SYSTEM INFORMATION	20-01
BASIC TROUBLESHOOTING	80-01	HYDRAULIC PUMP	20-01
BATTERY	60-01	HYDROSTATIC MOTOR	30-01
BICS™ SYSTEM	60-01	HYDROSTATIC PUMP	30-01
BOBCAT CONTROLLER	60-01	HYDROSTATIC SYSTEM INFORMATION.....	30-01
BOB-TACH.....	10-01, 50-01		
BRAKE	40-01	INSTRUMENT PANEL	60-01
BUCKET POSITION VALVE.....	20-01		
		LIFT ARM	50-01
CHARGE PRESSURE	30-01	LIFT ARM BY-PASS CONTROL VALVE.....	20-01
COMPONENTS	80-01	LIFT ARM SUPPORT DEVICE.....	10-01
CONTROL HANDLE	50-01	LIFTING AND BLOCKING THE LOADER.....	10-01
CONTROL PANEL	50-01	LIGHTS.....	60-01
CONTROL PEDALS	50-01	LOADER SPECIFICATIONS	SPEC-01
CONTROL PEDALS (ACS)	50-01	LUBRICATION OF THE BOBCAT LOADER	10-01
CONVERSIONS	SPEC-01		
COOLING FAN	70-01	MAIN RELIEF VALVE	20-01
CYLINDER (LIFT).....	20-01	MUFFLER.....	70-01
CYLINDER (POWER BOB-TACH).....	20-01		
CYLINDER (TILT)	20-01	OIL COOLER.....	30-01
		OPERATOR CAB	10-01, 50-01
DIAGNOSTICS SERVICE CODES.....	60-01	OPERATOR SEAT	50-01
DRIVE BELT	30-01		
DRIVE COMPONENTS	40-01	POWER BOB-TACH.....	10-01, 50-01
		POWER BOB-TACH BLOCK.....	20-01
ELECTRICAL/HYD. CONTROLS REFERENCE	60-01	RADIATOR.....	70-01
ELECTRICAL SYSTEM INFORMATION	60-01	REAR AUXILIARY DEVERTER	20-01
ENGINE	70-01	REAR DOOR	50-01
ENGINE COMPONENTS AND TESTING	70-01	REAR GRILL	50-01
ENGINE COOLING SYSTEM.....	10-01	RECONDITIONING THE ENGINE	70-01
ENGINE LUBRICATION SYSTEM	10-01	REGULAR MAINTENANCE	80-01
ENGINE SPECIFICATIONS.....	SPEC-01	REMOTE START	10-01
ENGINE SPEED CONTROL	70-01		
		SEAT BAR.....	50-01
FAN GEARBOX	10-01	SEAT BAR SENSOR.....	60-01
FINAL DRIVE TRANSMISSION (CHAINCASE).....	10-01	SERVICE SCHEDULE.....	10-01
FLYWHEEL AND HOUSING.....	70-01	SPARK ARRESTOR MUFFLER.....	10-01
FLYWHEEL RPM SENSOR.....	60-01	STARTER	60-01
FRONT AUXILIARY HYDRAULIC		SYSTEM TROUBLESHOOTING CHART	80-01
COUPLER BLOCK	20-01		
FUEL SYSTEM	10-01	TORQUE SPECIFICATIONS FOR BOLTS	SPEC-01
FUEL TANK.....	50-01	TOWING THE LOADER	10-01
		TRACTION LOCK	60-01
HEATER UNIT	80-01	TRANSPORTING THE LOADER	10-01
HEATER COIL	80-01	TROUBLESHOOTING	70-01
HEATER FAN	80-01		
HEATER VALVE.....	80-01		
HYDRAULIC CONNECTION SPECS.....	SPEC-01		
HYDRAULIC CONTROL VALVE (ADVANCED			
CONTROL SYSTEM) (ACS).....	20-01		
HYDRAULIC CONTROL VALVE			
(FOOT CONTROL)	20-01		