


[Click here to get the complete manual](#)



2410

S/N 13001 & Above

SERVICE MANUAL



CONTENTS

| | |
|---|-----|
| SAFETY INSTRUCTIONS..... | i |
| SERIAL NUMBER LOCATIONS..... | ii |
| DELIVERY REPORT..... | ii |
| BOBCAT ARTICULATED LOADER IDENTIFICATION..... | iii |
| PREVENTIVE MAINTENANCE..... | 1-1 |
| HYDRAULIC SYSTEM..... | 2-1 |
| HYDROSTATIC SYSTEM..... | 3-1 |
| DRIVE SYSTEM..... | 4-1 |
| MAIN FRAME..... | 5-1 |
| ELECTRICAL SYSTEM..... | 6-1 |
| ENGINE SERVICE..... | 7-1 |
| SPECIFICATIONS..... | 8-1 |

**PREVENTIVE
MAINTENANCE**

**HYDRAULIC
SYSTEM**

**HYDROSTATIC
SYSTEM**

**DRIVE
SYSTEM**

**MAIN
FRAME**

**ELECTRICAL
SYSTEM**

**ENGINE
SERVICE**

SPECIFICATIONS