


# BL-275

**IR** Ingersoll-Rand®

# Service Manual

(S/N 570811001 & Above)



*Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Bobcat Company or the products of either.*

**IR** Ingersoll-Rand®

## ALPHABETICAL INDEX

AIR CLEANER .....	70-01	HEATER FAN .....	80-01
AIR CLEANER SERVICE .....	10-01	HEATER UNIT .....	80-01
ALTERNATOR .....	60-01	HYDRAULIC FILTER HOUSING .....	20-01
ALTERNATOR BELT .....	10-01	HYDRAULIC FLUID RESERVOIR .....	20-01
ARM CYLINDER .....	20-01	HYDRAULIC SYSTEM INFORMATION .....	20-01
ARM .....	50-01	HYDRAULIC/HYDROSTATIC FLUID SPECIFICATIONS .....	SPEC-01
AXLE AND DIFFERENTIAL (FRONT) .....	40-01	HYDRAULIC/HYDROSTATIC SYSTEM .....	10-01
AXLE AND DIFFERENTIAL (REAR) .....	40-01	HYDROSTATIC DRIVE MOTOR .....	30-01
AXLE TOE-IN .....	10-01	HYDROSTATIC PUMP .....	30-01
		HYDROSTATIC SYSTEM INFORMATION .....	30-01
		HYDROSTATIC TESTING .....	30-01
BACKHOE BOOM LOCK .....	10-01		
BACKHOE CONTROL VALVE .....	20-01	INSTRUMENT PANEL .....	60-01
BATTERY .....	60-01		
BOB-TACH .....	50-01	LOADER BACKHOE SPECIFICATIONS .....	SPEC-01
BOB-TACH HAND LEVER .....	10-01	LOADER BACKHOE TORQUE .....	SPEC-01
BOOM .....	50-01	LOADER CONTROL VALVE .....	20-01
BOOM CYLINDER .....	20-01	LIFT ARMS .....	50-01
BRAKE CALIPER .....	40-01	LIFT ARM SUPPORT DEVICE .....	10-01
BUCKET .....	50-01	LIFT CYLINDER .....	20-01
BUCKET CYLINDER .....	20-01	LIFTING AND BLOCKING THE LOADER BACKHOE .....	10-01
		LUBRICATING THE LOADER BACKHOE .....	10-01
CAB DOOR .....	50-01		
CAB LIGHTS .....	60-01	MAIN RELIEF VALVE .....	20-01
COMPONENTS .....	80-01	MUFFLER .....	70-01
CONVERSIONS .....	SPEC-01		
		OIL COOLER .....	30-01
DRIVESHAFT .....	40-01	OPERATOR CAB .....	50-01
DROP BOX .....	40-01	OPERATOR SEAT .....	50-01
ELECTRICAL SYSTEM INFORMATION .....	60-01	PARKING BRAKE .....	40-01
ENCLOSED CAB .....	50-01	PORT RELIEF VALVE (BACKHOE CONTROL VALVE) .....	20-01
ENGINE .....	70-01	PORT RELIEF VALVE (LOADER CONTROL VALVE) .....	20-01
ENGINE COMPONENTS AND TESTING .....	70-01		
ENGINE COOLING SYSTEM .....	10-01	RADIATOR .....	70-01
ENGINE COVER .....	10-01, 50-01	REAR AXLE .....	10-01, 40-01
ENGINE LUBRICATION SYSTEM .....	10-01	REAR WINDOW .....	50-01
ENGINE SIDE COVERS .....	50-01	REAR WIPER .....	60-01
ENGINE SPECIFICATIONS .....	SPEC-01	RECONDITIONING THE ENGINE .....	70-01
ENGINE SPEED CONTROL .....	70-01	RUBBER DRIVE COUPLER .....	70-01
FENDER .....	50-01	SERVICE SCHEDULE .....	10-01
FLOOR PANELS .....	50-01	SIDE SHIFT LOCK CYLINDER .....	20-01
FLYWHEEL .....	70-01	STABILIZER FRAME .....	50-01
FLYWHEEL HOUSING .....	70-01	STABILIZER CYLINDER .....	20-01
FRONT AXLE .....	10-01, 40-01	STEERING ANGLE ADJUSTMENT (FRONT AXLE) .....	40-01
FRONT AXLE PIVOT FRAME .....	50-01	STEERING ANGLE ADJUSTMENT (REAR AXLE) .....	40-01
FRONT LIGHTS .....	60-01	STEERING CYLINDER (FRONT) .....	20-01
FRONT WIPER .....	60-01	STEERING CYLINDER (REAR) .....	20-01
FUEL LEVEL SENDER .....	60-01	STEERING PUMP .....	20-01
FUEL SYSTEM .....	10-01	STEERING VALVE .....	20-01
FUEL TANK .....	50-01		
GEAR PUMP .....	20-01		
GRILL .....	50-01		
GRILL FRAME .....	50-01		

## ALPHABETICAL INDEX (CONT'D)

STARTER .....	60-01
SWING CYLINDER .....	20-01
SWING FRAME .....	50-01
TILT CYLINDER .....	20-01
TIRE MAINTENANCE .....	10-01
TORQUE SPECIFICATIONS	
FOR BOLTS .....	SPEC-01
TOWING THE LOADER BACKHOE .....	10-01
TRANSPORTING THE LOADER BACKHOE .....	10-01
TRAVEL PEDAL .....	20-01
TROUBLESHOOTING .....	70-01
TURBOCHARGER .....	70-01
TURN INDICATOR LIGHTS (FRONT) .....	60-01
TURN INDICATOR LIGHTS (REAR) .....	60-01
X-CHANGE™ .....	50-01

# CONTENTS

FOREWORD.....	II
SAFETY INSTRUCTIONS FOR INGERSOLL RAND LOADER BACKHOE AND ATTACHMENTS.....	V
SERIAL NUMBER LOCATION .....	VII
FIRE PREVENTION .....	VI
DELIVERY REPORT.....	VII
INGERSOLL RAND LOADER IDENTIFICATION .....	VIII
SAFETY & MAINTENANCE .....	10-01
HYDRAULIC SYSTEM .....	20-01
HYDROSTATIC SYSTEM.....	30-01
DRIVE SYSTEM .....	40-01
MAIN FRAME .....	50-01
ELECTRICAL SYSTEM AND ANALYSIS .....	60-01
ENGINE SERVICE .....	70-01
HEATER .....	80-01
SPECIFICATIONS.....	SPEC-01

**SAFETY &  
MAINTENANCE**

**HYDRAULIC  
SYSTEM**

**HYDROSTATIC  
SYSTEM**

**DRIVE  
SYSTEM**

**MAIN FRAME**

**ELECTRICAL  
SYSTEM &  
ANALYSIS**

**ENGINE  
SERVICE**

**HEATER**

**SPECIFICATIONS**