


# BL-370

## B Series



# Service Manual

**S/N 572711001 & Above**



Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Bobcat Company or the products of either.

## ALPHABETICAL INDEX

AIR CLEANER .....	70-01	HYDRAULIC FLUID RESERVOIR .....	20-01
AIR CLEANER SERVICE .....	10-01	HYDRAULIC SYSTEM INFORMATION .....	20-01
ALTERNATOR .....	60-01	HYDRAULIC/HYDROSTATIC FLUID	
ALTERNATOR BELT .....	10-01	SPECIFICATIONS .....	SPEC-01
APPROVED LIFT ARM SUPPORT DEVICE	10-01	HYDRAULIC/HYDROSTATIC SYSTEM.....	10-01
ARM CYLINDER .....	20-01	HYDROSTATIC DRIVE MOTOR .....	30-01
ARM .....	50-01	HYDROSTATIC PUMP .....	30-01
AXLE TOE-IN.....	10-01	HYDROSTATIC SYSTEM INFORMATION.....	30-01
		HYDROSTATIC TESTING.....	30-01
BACKHOE CONTROL VALVE.....	20-01		
BATTERY .....	60-01	INSTRUMENT PANEL.....	60-01
BOB-TACH.....	50-01		
BOB-TACH HAND LEVER.....	10-01	LIFT ARMS.....	50-01
BOOM .....	50-01	LIFT ARM STABILIZER.....	50-01
BOOM CYLINDER.....	20-01	LIFT CYLINDER.....	20-01
BOOM LOCK PIN .....	10-01	LIFTING AND BLOCKING THE	
BUCKET .....	50-01	LOADER BACKHOE .....	10-01
BUCKET CYLINDER .....	20-01	LOADER BACKHOE SPECIFICATIONS.....	SPEC-01
BUCKET POSITIONING LINK.....	50-01	LOADER BACKHOE TORQUE .....	SPEC-01
		LOADER CONTROL VALVE .....	20-01
CAB LIGHTS.....	60-01	LUBRICATING THE LOADER BACKHOE .....	10-01
CENTER FLOOR PANEL .....	50-01		
CONVERSIONS .....	SPEC-01	MAIN RELIEF VALVE .....	20-01
		MASTER CYLINDER .....	20-01
DRIVE COUPLER.....	70-01	MUFFLER.....	70-01
DRIVESHAFT .....	40-01		
DROP BOX .....	40-01	OIL COOLER.....	30-01
		OPERATOR CANOPY.....	50-01
ELECTRICAL SYSTEM INFORMATION .....	60-01	OPERATOR SEAT .....	50-01
ENCLOSED CAB.....	50-01		
ENGINE .....	70-01	PARKING BRAKE HOUSING.....	40-01
ENGINE COMPONENTS AND TESTING .....	70-01	PORT RELIEF VALVE	
ENGINE COOLING SYSTEM.....	10-01	(BACKHOE CONTROL VALVE) .....	20-01
ENGINE COVER .....	10-01, 50-01		
ENGINE LUBRICATION SYSTEM.....	10-01	RADIATOR .....	70-01
ENGINE SIDE COVERS.....	50-01	REAR AXLE .....	10-01, 40-01
ENGINE SPECIFICATIONS.....	SPEC-01	RECONDITIONING THE ENGINE .....	70-01
ENGINE SPEED CONTROL .....	70-01		
		SERVICE SCHEDULE .....	10-01
FENDER .....	50-01	STABILIZER .....	50-01
FLOOR PANELS.....	50-01	STABILIZER CYLINDER (FRONT & REAR).....	20-01
FLYWHEEL.....	70-01	STEERING CYLINDER .....	20-01
FLYWHEEL HOUSING .....	70-01	STEERING PUMP .....	20-01
FRONT AXLE .....	10-01, 40-01	STEERING VALVE .....	20-01
FRONT AXLE PIVOT FRAME .....	50-01	STARTER .....	60-01
FRONT LIGHTS.....	60-01	SWING CYLINDER .....	20-01
FUEL LEVEL SENDER.....	60-01	SWING FRAME .....	50-01
FUEL SYSTEM .....	10-01		
FUEL TANK.....	50-01	TILT CYLINDER .....	20-01
		TIRE MAINTENANCE .....	10-01
GEAR PUMP .....	20-01	TORQUE SPECIFICATIONS	
GRILL.....	50-01	FOR BOLTS.....	SPEC-01
GRILL FRAME .....	50-01	TOWING THE LOADER BACKHOE .....	10-01
		TRANSPORTING THE LOADER BACKHOE.....	10-01
HYDRAULIC FILTER .....	20-01	TRAVEL PEDAL .....	70-01
HYDRAULIC FILTER HOUSING .....	20-01		

## ALPHABETICAL INDEX (CONT'D)

TROUBLESHOOTING.....	40-01, 70-01
TURBO .....	70-01
TURN INDICATOR LIGHTS (FRONT).....	60-01
TURN INDICATOR LIGHTS (REAR).....	60-01
X-CHANGE™ .....	50-01

# CONTENTS

FOREWORD.....	II
SAFETY INSTRUCTIONS .....	V
SERIAL NUMBER LOCATION .....	VII
DELIVERY REPORT.....	VII
LOADER BACKHOE IDENTIFICATION .....	VIII
SAFETY AND MAINTENANCE.....	10-01
HYDRAULIC SYSTEM .....	20-01
HYDROSTATIC SYSTEM.....	30-01
DRIVE SYSTEM .....	40-01
MAIN FRAME .....	50-01
ELECTRICAL SYSTEM AND ANALYSIS .....	60-01
ENGINE SERVICE .....	70-01
SPECIFICATIONS.....	SPEC-01

**SAFETY &  
MAINTENANCE**

**HYDRAULIC  
SYSTEM**

**HYDROSTATIC  
SYSTEM**

**DRIVE  
SYSTEM**

**MAIN FRAME**

**ELECTRICAL  
SYSTEM &  
ANALYSIS**

**ENGINE  
SERVICE**

**SPECIFICATIONS**