


[Click here to get the complete manual](#)

[CLICK HERE FOR
TABLE OF
CONTENTS](#)



TR45 Off-Highway Trucks Service Manual



[CLICK HERE TO RETURN TO
MAIN LIBRARY INDEX](#)

TECHNICAL PUBLICATIONS DEPARTMENT
TEREX EQUIPMENT LIMITED,
MOTHERWELL, SCOTLAND, ML1 5RY
REF. NO. SM754/781

TABLE OF CONTENTS

Section No.	Description	SM No.
000 0000	GENERAL INFORMATION TR45 Off-Highway Truck	1608
100 0010	CHASSIS Chassis, Hood and Fenders	1570
110 0030 0050 0130	ENGINE Engine and Mounting Air Cleaner Power Takeoff	1571 1572 1296
120 0010 0070 0070 0090 0100	TRANSMISSION Transmission and Mounting Commercial Electronic Control (CEC) Shift System Commercial Electronic Control 2 (CEC2) Power Takeoff Transmission Oil Filter	1612 1575 2128 1178 1576
130 0010 0010 0020 0020	DRIVELINE Front Driveline - Pre June 1998 Production Front Driveline - From June 1998 Production Rear Driveline - Pre June 1998 Production Rear Driveline - From June 1998 Production	1180 1577 1311 1578
140 0040	FRONT AXLE Wheel, Rim and Tyre	1303
160 0020 0030 0050	REAR AXLE Differential Axle Group Wheel, Rim and Tyre	1298 1299 1300 Rev 1
165 0020 0030	BRAKE PARTS Brake Parts - Front Axle Brake Parts - Rear Axle	1186 1301
180 0030 0050	SUSPENSION SYSTEM Ride Cylinder - Front Ride Cylinder - Rear	1584 1302
190 0000 0270	CIRCUIT DIAGRAMS Circuit Diagrams Switches and Sensors	1585 1586
200 0010 0040 0051	FUEL SYSTEM Fuel Tank and Mounting Fuel Lines Electronic Foot Pedal	1587 1195 1196
210 0000 0040 0050 0060	COOLING SYSTEM Cooling System Radiator, Header Tank and Mounting Disc Brake Oil Cooler Transmission Oil Cooler	1305 1613 1589 1590