


[Click here to get the complete manual](#)

[CLICK HERE FOR
TABLE OF
CONTENTS](#)



S17E Elevating Scraper Maintenance Manual



[CLICK HERE TO RETURN TO
MAIN LIBRARY INDEX](#)

TECHNICAL PUBLICATIONS DEPARTMENT
TEREX EQUIPMENT LIMITED,
MOTHERWELL, SCOTLAND, ML1 5RY
REF. NO. 831

TABLE OF CONTENTS

Section No.	Description	SM No.
000 0000	GENERAL INFORMATION S17E Technical Data	2049
100 0010 0130	CHASSIS Chassis, Hood and Fenders - Tractor Steering Trunnion - Tractor	1885 1695
110 0030 0050 0130	ENGINE Engine and Mounting Air Cleaner Power Takeoff - Tractor	2050 2051 1693
120 0010 0070	TRANSMISSION Transmission Mounting Transmission Electronic Controls	2052 2053
130 0010	DRIVELINE Drivelines - Front	2054
140 0030 0040 0060 0100 0110 0130	FRONT AXLE GROUP Planetary Gearing Wheel, Rim and Tyre Differential - Power Locking Control Valve - Diff-Lock Pump - Diff-Lock Filter and Regulator - Front Diff	2055 2056 2057 2096 2097 2098
165 0031 0031 0060	BRAKE PARTS Brake Parts - Tractor Brake Parts - Scraper Slack Adjuster	2093 2094 1751
190 0000 0270	ELECTRICAL SYSTEM Circuit Diagrams Switches and Sensors	2072 2058
200 0040 0051	FUEL SYSTEM Fuel Tank, Lines and Mounting Electronic Foot Pedal	2059 2060
210 0000 0040	COOLING SYSTEM Cooling System Radiator and Mounting	2100 2099
220 0000 0010 0090 0120 0130 0160 0190	STEERING SYSTEM - TRACTOR Steering System Schematic Steering Lines and Fittings Steering Valve Steering Cylinder Double Relief Valve Flow Reversing Valve Steering Linkage	1760 2095 1765 1897 1747 1764 1766
235 0000 0010 0020 0040 0050 0060 0070 0080 0090 0100 0120 0160 0160	BOWL HYDRAULIC SYSTEM Hydraulic System Schematic Hydraulic Lines and Fittings Bowl Cylinder Hydraulic Tank - Tractor Triple Pump Bowl Control Valve Accumulator Endgate Cylinder Floor Cylinder Sequence Valve Relief Valve Servo Control Valve - Bowl and Ejector Servo Control Valve - Elevator	2061 2062 1769 2063 1739 2070 2071 2073 2074 2107 1776 2104 2106