


[Click here to get the complete manual](#)

[CLICK HERE FOR
TABLE OF
CONTENTS](#)



TA25 & TA27 Articulated Dumptruck Maintenance Manual



[CLICK HERE TO RETURN TO
MAIN LIBRARY INDEX](#)

TECHNICAL PUBLICATIONS DEPARTMENT
TEREX EQUIPMENT LIMITED
MOTHERWELL, SCOTLAND ML1 5RY
REF. NO. SM 805

TABLE OF CONTENTS

Section No.	Description	SM No.
000	GENERAL INFORMATION	
0000	Technical Data - TA25	2004
0000	Technical Data - TA27	2005
100	CHASSIS	
0010	Frames	1960 Rev 1
0020	Articulation and Oscillation Pivot	1988 Rev 1
0040	Hood and Mounting	1984 Rev 1
0070	Fenders and Mounting	1995
110	ENGINE	
0030	Engine and Mounting	2006
0040	Kysor DST Fan	1974
0050	Air Cleaner	2007
0080	Exhaust Brake	2008 Rev 1
120	TRANSMISSION	
0010	Transmission and Mounting	2009 Rev 1
130	DRIVELINES	
0010	Front and Rear Drivelines	2010
140	FRONT AXLE GROUP	
0020	Axle Group (Hub)	(Refer to Section 160-0030)
0040	Wheel Rim and Tyre	(Refer to Section 160-0050)
0060	Differential Drive Head	(Refer to Section 160-0020)
150	CENTRE AXLE	
0020	Differential Drive Head	1971
160	REAR AXLE GROUP	
0020	Differential Drive Head	1969
0030	Axle Group (Hub)	1968
0050	Wheel Rim and Tyre	1970
165	BRAKE PARTS	
0010	Brake Parts - Rear	1962
0020	Brake Parts - Front	1961
170	PARKING BRAKE	
0010	Parking Brake and Mounting	1967
180	SUSPENSION SYSTEM	
0020	Front Suspension	1979
0021	Air Spring	1480
0022	Levelling Valve	1481
0040	Rear Suspension	1978
190	ELECTRICAL SYSTEM	
0000	Circuit Diagrams	1808 Rev 2
0270	Switches and Sensors	2011 Rev 1
200	FUEL SYSTEM	
0040	Fuel Tank, Lines and Mounting	2012