

[Click here to get the complete manual](#)

[CLICK HERE FOR
TABLE OF
CONTENTS](#)

TEREX 

TA30 Articulated Dumptruck Service Manual



[CLICK HERE TO RETURN TO
MAIN LIBRARY INDEX](#)

TECHNICAL PUBLICATIONS DEPARTMENT
TEREX EQUIPMENT LIMITED
MOTHERWELL, SCOTLAND ML1 5RY
REF. NO. SM 775

TABLE OF CONTENTS

Section No.	Description	SM No.
000	GENERAL INFORMATION	
0000	Technical Data - TA30	1528
100	CHASSIS	
0010	Frames	1462 Rev 1
0020	Articulation and Oscillation Pivot	1529
0040	Hood and Mounting - Pre March 1999 Production	1530
0040	Hood and Mounting - From March 1999 Production	1805
0070	Fenders and Mounting - Pre June 1999 Production	1531
0070	Fenders and Mounting - From June 1999 Production	1809
110	ENGINE	
0030	Engine and Mounting - Pre March 1999 Production	1532
0030	Engine and Mounting - From March 1999 Production	1810
0040	Kysor DST Fan	1518
0050	Air Cleaner - Pre May 1999 Production	1468
0050	Air Cleaner - From May 1999 Production	1811
120	TRANSMISSION	
0010	Transmission and Mounting	1533 Rev 1
130	DRIVELINES	
0010	Front and Rear Drivelines	1534
140	FRONT AXLE GROUP	
0020	Axle Group (Hub) (Refer to Section 160-0030)	-
0040	Wheel Rim and Tyre (Refer to Section 160-0050)	-
0060	Differential Drive Head (Refer to Section 160-0020)	-
150	CENTRE AXLE	
0020	Differential Drive Head	1472
160	REAR AXLE GROUP	
0020	Differential Drive Head	1473
0030	Axle Group (Hub)	1474
0050	Wheel Rim and Tyre	1475
165	BRAKE PARTS	
0010	Brake Parts - Rear	1476
0020	Brake Parts - Front (Refer to Section 165-0010)	-
170	PARKING BRAKE	
0010	Parking Brake and Mounting	1477
180	SUSPENSION SYSTEM	
0020	Front Suspension	1479
0021	Air Spring	1480
0022	Levelling Valve	1481
0040	Rear Suspension	1482
190	ELECTRICAL SYSTEM	
0000	Circuit Diagrams - Pre June 1999 Production	1535
0000	Circuit Diagrams - From June 1999 Production	1812
0270	Switches and Sensors	1536

TABLE OF CONTENTS

Section No.	Description	SM No.
200	FUEL SYSTEM	
0040	Fuel Tank, Lines and Mounting	1537
210	COOLING SYSTEM	
0000	Cooling System - Pre March 1999 Production	1538
0000	Cooling System - From March 1999 Production	1818
0040	Radiator and Mounting - Pre March 1999 Production	1487
0040	Radiator, Header Tank and Mounting - From March 1999 Production	1813
0060	Transmission Oil Cooler - Pre June 1999 Production	1488
0060	Transmission Oil Cooler - From June 1999 Production	1814
0100	Hydraulic Oil Cooler	1556
220	STEERING SYSTEM	
0000	Steering System Schematic	1817
0050	Steering Pump	1540
0070	Accumulator Valve	1541
0080	Accumulator	1542
0090	Steering Valve	1543
0120	Steering Cylinder	1495
0130	Crossover Relief Valve	1544
0150	Steering Filter	1545
230	BODY SYSTEM	
0000	Body System Schematic	1816
0040	Hydraulic Tank	1547
0050	Hydraulic Pump	1548
0060	Body Control Valve	1549
0081	Body Control Joystick	1411
0121	Pilot Supply Valve	1550
0130	Body Cylinder	1501
250	BRAKING SYSTEM	
0000	Air Braking System Schematic - Pre June 1999 Production	1551
0000	Air Braking System Schematic - From June 1999 Production	1815
0000	Hydraulic Braking System Schematic	1503
0070	Treadle Valve	1552
0170	Air Tanks and Mounting	1553
0171	Pressure Protection Valve	1561
0172	Relief Valve	1562
0173	Check Valve	1563
0190	Park Emergency Control Valve	1554
0200	Air Drier - Pre June 1999 Production	1555
0200	Air Drier - From June 1999 Production	1507 Rev 1
0260	Pressure Converter	1508
0270	Air Breather	1509
0280	Relay Emergency Valve	1510

TABLE OF CONTENTS

Section No.	Description	SM No.
260	OPERATORS COMPARTMENT	
0010	Cab and Mounting	1614
0090	Driver Seat and Mounting	1804
0130	Air Conditioning	1557
270	BODY	
0010	Body and Mounting	1558
300	MISCELLANEOUS	
0020	Lubrication System	1559 Rev 2
0070	Service Tools	1560 Rev 1
0080	Axle Bolt and Nut Torque Specifications	1521
0080	Standard Bolt and Nut Torque Specifications	1238
0090	Unit Storage	1239

* * * *