

[Click here to get the complete manual](#)


[CLICK HERE FOR
TABLE OF
CONTENTS](#)



TA35

Articulated Dumptruck

Maintenance Manual



[CLICK HERE TO RETURN TO
MAIN LIBRARY INDEX](#)

TECHNICAL PUBLICATIONS DEPARTMENT
TEREX EQUIPMENT LIMITED
MOTHERWELL, SCOTLAND ML1 5RY
REF. NO. SM836

TABLE OF CONTENTS

Section No.	Description	SM No.
000	GENERAL INFORMATION	
0000	Technical Data - TA35	2109
100	CHASSIS	
0010	Frames	1372 Rev 1
0020	Articulation and Oscillation Pivot	1373 Rev 1
0040	Hood and Mounting	2120
110	ENGINE	
0030	Engine and Mounting	2121
0050	Air Cleaner	2122
120	TRANSMISSION	
0010	Transmission and Mounting	2124
130	DRIVELINES	
0010	Front Drivelines	1378 Rev 1
0020	Rear Drivelines	1379 Rev 1
140	FRONT AXLE GROUP	
0020	Axle Group (Hub)	(Refer to Section 160-0030)
0040	Wheel Rim and Tyre	(Refer to Section 160-0050)
0060	Differential Drive Head	1387 Rev 1
150	CENTRE AXLE	
0020	Differential Drive Head	1385 Rev 1
160	REAR AXLE GROUP	
0020	Differential Drive Head	1380 Rev 1
0030	Axle Group (Hub)	1381
0050	Wheel Rim and Tyre	1382
165	BRAKE PARTS	
0010	Brake Parts - Rear	1383 Rev 1
0020	Brake Parts - Front	(Refer to Section 165-0010)
170	PARKING BRAKE	
0010	Parking Brake and Mounting	2108
0030	Actuator	2125
180	SUSPENSION SYSTEM	
0020	Front Suspension	2119
0040	Rear Suspension	1384 Rev 1
190	ELECTRICAL SYSTEM	
0000	Circuit Diagrams (DDEC III & IV, 6WG 310 transmission)	2126
0270	Switches and Sensors	2127
200	FUEL SYSTEM	
0040	Fuel System	1398 Rev 1
0051	Electronic Foot Pedal	1399