

[Click here to get the complete manual](#)

[CLICK HERE FOR
TABLE OF
CONTENTS](#)

TEREX 

2566C, 2766C and 3066C Articulated Dumptruck Service Manual



[CLICK HERE TO RETURN TO
MAIN LIBRARY INDEX](#)

TECHNICAL PUBLICATIONS DEPARTMENT
TEREX EQUIPMENT LIMITED
MOTHERWELL, SCOTLAND ML1 5RY
REF. NO. SM 700/710/734

TABLE OF CONTENTS

2566C, 2766C and 3066C

Section No.	Description	SM No.
0	GENERAL INFORMATION (Specification)	
0	General Information (2566C)	962
0	General Information (2766C)	963
0	General Information (3066C)	964 Rev 1
1	CHASSIS	
1-1	Frames	2 Rev 2
1-1A	Articulation and Oscillation Pivot	635 Rev 1
1-2	Hood and Cowl	978
1-3	Fenders and Mounting	1150
2	ENGINE AND MOUNTING	
2-2	Engine and Mounting (2566C and 2766C)	966 Rev 1
2-2	Engine and Mounting (3066C)	967 Rev 1
2-2A	Viscous Fan	396 Rev 1
2-3	Air Cleaner	979
2-5A	Exhaust Brake (2566C Only)	1139
6	TRANSMISSION	
6-1	Transmission and Mounting (2566C and 2766C)	99 Rev 6
6-1	Transmission and Mounting (3066C)	981
6-1	Transmission and Mounting (3066C with 6WG 260 Transmission)	1367
7	DRIVELINES	
7-1	Front and Rear Drivelines	863
8	REAR AXLE GROUP	
8-1	Differential	8 Rev 4
8-2	Axle Group	112 Rev 5
8-3	Wheel Rim and Tyre	864
8-4	Brake Parts	49 Rev 6
8-7	Rear Suspension	860
8-31	Differential (Centre Axle)	188 Rev 3
9	FRONT AXLE GROUP	
9-1	Axle Group (Refer to Section 8-2)	-
9-3	Wheel Rim and Tyre (Refer to Section 8-3)	-
9-4	Brake Parts (Refer to Section 8-4)	-
9-6	Front Suspension	406 Rev 3
9-6	Air Spring	55 Rev 4
9-7	Levelling Valve	408
9-9	Differential (Refer to Section 8-1)	-
10	PARKING BRAKE	
10-2	Parking Brake and Mounting	407
11	AIR SYSTEM	
11-0	Air System Schematic	985
11-32	Pressure Protection Valve	21 Rev 3
11-33	Safety Valve	22 Rev 3
11-33	Check Valve (One Way)	56 Rev 2