


[Click here to get the complete manual](#)

[CLICK HERE FOR
TABLE OF
CONTENTS](#)



3340 and 3345 Off-Highway Trucks Service Manual



[CLICK HERE TO RETURN TO
MAIN LIBRARY INDEX](#)

TECHNICAL PUBLICATIONS DEPARTMENT
TEREX EQUIPMENT LIMITED,
MOTHERWELL, SCOTLAND, ML1 5RY
REF. NO. SM507

TABLE OF CONTENTS

Section No.	Description	SM No.
0	GENERAL INFORMATION	
0	3340 Off-Highway Truck	797 Rev 4
0	3345 Off-Highway Truck	798 Rev 2
1	CHASSIS	
1	Chassis, Hood and Fenders	841
2	ENGINE	
2-2	Engine and Mounting (Cummins)	819 Rev 1
2-2	Engine and Mounting (Detroit Diesel)	1011
2-3	Air Cleaner	846 Rev 2
2-12	Power Takeoff	820
4	TRANSMISSION	
4-1	Transmission and Mounting	821 Rev 1
4-12	ATEC Plus II Shift System	822 Rev 2
4-14	Power Takeoff	838 Rev 1
4-16	Transmission Oil Filter	837
7	DRIVELINE	
7-1	Front Driveline	653 Rev 1
7-2	Rear Driveline	655
8	REAR AXLE	
8-1	Differential	835
8-2	Axle Group	834
8-3	Wheel, Rim and Tyre	831 Rev 1
8-4	Brake Parts	830 Rev 2
8-13	Ride Cylinder	827 Rev 1
9	FRONT AXLE	
9-3	Wheel, Rim and Tyre	829 Rev 2
9-4	Brake Parts	678 Rev 2
9-13	Ride Cylinder	828 Rev 1
12	STEERING SYSTEM	
12-0	Steering System Schematic	914 Rev 2
12-1A	Steering Valve - Pre July 1995 Production	684 Rev 2
12-1A	Steering Valve - From July 1995 Production	903
12-5	Steering Cylinder and Linkage	911
12-7	Steering Pump	688 Rev 2
12-9	Steering and Brake Control Tank	803 Rev 2
12-15	Accumulator	692 Rev 1
12-16	Accumulator Valve	804
12-16A	Double Relief Valve	805
13	CIRCUIT DIAGRAMS	
13-1	Circuit Diagrams	959
13-1	Circuit Diagrams (DDEC III)	See Note
13-29	Switches and Sensors	1003
13-29	Switches and Sensors (Series 60 Engine)	997
15	FUEL SYSTEM	
15-1	Fuel Tank and Mounting	850
15-2	Fuel Lines (Series 60 Engine)	1017
15-4	Electronic Foot Pedal (Series 60 Engine)	996

Note: Sections in process for issue later.