

[Click here to get the complete manual](#)



E16 - E18

WORKSHOP MANUAL
ENGLISH

Print No. 604.13.396

Edition: 01/2005
English - Printed in Italy

Printed by Studio ti - 12105

TO THE READER

- This manual has been written for a skilled technician, in order to give him the information necessary to repair this machine.
- Read this manual carefully for correct information about repair procedures.
- For any question or comment, or in case you notice a mistake in this manual content, please contact:

NEWHOLLANDKOBELCOCONSTRUCTION
MACHINERY S.p.A.
Strada di Settimo, 323
San Mauro Torinese (TO)
10099 ITALIA
PRODUCT SUPPORT
Fax. ++39 011 0077357

ADDITIONAL REFERENCE MANUALS

- In addition to this Workshop Manual, refer also to the following:
 - Operation and maintenance instruction manual
 - Spare parts catalog

DESCRIPTION OF THE COMPLETE WORKSHOP MANUAL

- The complete repair manual consists of two volumes:
 - E16 - E18**
Workshop Manual "Excavator"
- "Excavator" and "Engine" Workshop Manuals contain the technical information necessary for machine/engine service and repair, service equipment, information on maintenance standards, remove and install procedures, disassembly and assembly procedures.
- The complete Workshop Manual for the excavator models **E16 - E18** consists of the following volumes identified by print number as shown herebelow:

VOLUME	MACHINE TYPE	PRINT No.
- Workshop Manual - "Excavator"	E16 -E18	604.13.396