

[Click here to get the complete manual](#)

Open front screen




# TANDEM DRUM ROLLER

**SERVICE MANUAL SM71001**

May 2000

**Model 752C**



**CALIFORNIA**

**Proposition 65 Warning**

Diesel engine exhaust and some of its constituents are known  
to the State of California to cause cancer, birth defects, and  
other reproductive harm.

## **SECTION ONE**

<b>GENERAL INFORMATION .....</b>	<b>1 - 1</b>
MACHINE DESCRIPTION .....	1 - 3
MACHINE SERIAL NUMBERS .....	1 - 5
IDENTIFYING MACHINE COMPONENTS .....	1 - 6
MACHINE SPECIFICATIONS.....	1 - 8
STANDARD TORQUE DATA .....	1 - 10
FLUID CAPACITY - 752C .....	1 - 12
DIESEL FUEL SPECIFICATION .....	1 - 13
ENGINE OIL SPECIFICATION.....	1 - 14
ROLLOVER PROTECTION STRUCTURE .....	1 - 15
SAFETY, GENERAL .....	1 - 16
SPARK ARRESTER .....	1 - 16
SAFETY, PERSONAL .....	1 - 17
SAFETY, MACHINE OPERATION .....	1 - 19
SAFETY, MAINTENANCE .....	1 - 22
SAFETY, DECALS.....	1 - 23

## **SECTION TWO**

<b>ENGINE .....</b>	<b>2 - 1</b>
ENGINE DATA .....	2 - 2
CUMMINS ENGINE WARRANTY.....	2 - 3
ENGINE REMOVAL .....	2 - 4

## **SECTION THREE**

<b>ELECTRICAL.....</b>	<b>3 - 1</b>
INSTRUMENT PANEL, RIGHT.....	3 - 2
INSTRUMENT PANEL, LEFT.....	3 - 4
INSTRUMENT PANEL COVER.....	3 - 5
COMBINATION INDICATOR .....	3 - 6
SPEED RANGE CONTROL.....	3 - 7
UNDERSTANDING ELECTRICAL SCHEMATICS .....	3 - 11
UNDERSTANDING RELAYS .....	3 - 14
VIBROMAX RELAYS .....	3 - 15
STARTER/CHARGING CIRCUIT .....	3 - 17
UNDERSTANDING BATTERIES.....	3 - 17
BATTERY DIAGNOSTICS .....	3 - 18
UNDERSTANDING ALTERNATORS .....	3 - 19

CHARGING SYSTEM DIAGNOSTICS .....	3 - 20
VOLTAGE CHECKS AT ALTERNATOR .....	3 - 21
SYSTEM LEAKAGE .....	3 - 21
CIRCUIT WIRING TEST .....	3 - 21
MEASURING ALTERNATOR OUTPUT .....	3 - 22
UNDERSTANDING STARTERS .....	3 - 22
STARTER SOLENOID .....	3 - 23
STARTER SYSTEM DIAGNOSTICS .....	3 - 23
SOLENOID CIRCUIT TEST .....	3 - 23
STARTER CIRCUIT WIRING TEST .....	3 - 24
STARTER MOTOR TEST .....	3 - 25
INSTRUMENTATION PANEL.....	3 - 27
LIGHTING CIRCUIT .....	3 - 29
WATER SPRINKLER CIRCUIT .....	3 - 31
VIBRATION/DRUM SELECTION CIRCUITS.....	3 - 33
VIBRATION CONTROL CIRCUIT.....	3 - 35
TWO SPEED PROPULSION MOTOR CIRCUITS.....	3 - 37
WIRE CHART, RIGHT PANEL & HARNESS 4010/67455 .....	3 - 44
WIRE CHART, LEFT PANEL & HARNESS 4010/67413 .....	3 - 46
WIRE CHART, FRONT HARNESS 4010/67336 .....	3 - 48
WIRE CHART, REAR HARNESS 4010/68335 .....	3 - 49

## **SECTION FOUR**

<b>HYDRAULIC .....</b>	<b>4 - 1</b>
PROPULSION SYSTEM .....	4 - 5
VIBRATION SYSTEM .....	4 - 9
STEERING SYSTEM.....	4 - 13
BRAKE CIRCUIT .....	4 - 17
HYDRAULIC AND COOLING LINES .....	4 - 18
HYDRAULIC DRAIN SYSTEM .....	4 - 20
HYDRAULIC SYSTEM COMPONENTS .....	4 - 22
PRESSURE TEST POINTS .....	4 - 22
HYDRAULIC SCHEMATIC .....	4 - 23

## **SECTION FIVE**

<b>POWER TRAIN.....</b>	<b>5 - 1</b>
752C DRUM ASSEMBLY .....	5 - 3
DRUM REMOVAL.....	5 - 8
DRUM INSTALLATION .....	5 - 9
RIGHT SIDE BEARING COVER .....	5 - 10
DRUM DRIVE BEARING REMOVAL .....	5 - 11
DRUM DRIVE BEARING ASSEMBLY .....	5 - 12
DRUM DRIVE MOTOR REPAIRS .....	5 - 13
DRUM DRIVE GEARBOX.....	5 - 14
GFT 17 T2/312 2 GEARBOX .....	5 - 16

## **SECTION SIX**

<b>PARKING BRAKE SYSTEM .....</b>	<b>6 - 1</b>
BRAKE CIRCUIT .....	6 - 6
TOWING YOUR MACHINE .....	6 - 7

## **SECTION SEVEN**

<b>VIBRATION SYSTEM .....</b>	<b>7 - 1</b>
LIFTING DEVICE .....	7 - 2
DRUM EXCITER SHAFT .....	7 - 3
752C VIBRATION SYSTEM .....	7 - 4
VIBRATION SYSTEM .....	7 - 7
VIBRATION FREQUENCY .....	7 - 8
VIBRATION AMPLITUDE .....	7 - 9
VIBRATORY SYSTEM DIAGNOSTICS.....	7 - 10
752C DRUM DRAWING .....	7 - 11
DRUM - LEFT SIDE .....	7 - 12
DRUM - RIGHT SIDE .....	7 - 15
DRUM REMOVAL.....	7 - 18
DRUM INSTALLATION .....	7 - 19
RIGHT SIDE BEARING COVER .....	7 - 20
EXCITER BEARING REMOVAL .....	7 - 21
EXCITER BEARING ASSEMBLY .....	7 - 23