



# Service Manual

# Attachments

PUBLISHED BY THE  
TECHNICAL PUBLICATIONS DEPARTMENT  
OF JCB SERVICE: ©  
ROCESTER, STAFFORDSHIRE, ST14 5LS,  
ENGLAND  
Tel. ROCESTER (01889) 590312  
PRINTED IN ENGLAND

Publication No. 9803/1400

Introduction	<b>1</b>	Hi Tip Shovel	<b>11</b>
Compactor	<b>2</b>	*Drillmaster	<b>12</b>
Trencher	<b>3</b>	Sideshift	<b>13</b>
Earthdrill	<b>4</b>	Pole Planter	<b>14</b>
Patch Planer	<b>5</b>	Multihitch	<b>15</b>
Road Sweeper	<b>6</b>	Sweeper/ Collector - Sweepster	<b>16</b>
Sweeper/Collector	<b>7</b>	*Skidsteer Trencher 'C' Series	<b>17</b>
De Luxe Sweeper/Collector	<b>8</b>		
Silashear	<b>9</b>		
Side Tip Shovel	<b>10</b>		

<b>Contents</b>	<b>Page No.</b>
Introduction	1 - 1
Safety Notices	
Safety - Yours and Other Peoples	2 - 1
General Safety	2 - 1
Operating Safety	2 - 2
Maintenance Safety	2 - 3
* Travelling with the Attachment	2 - 4
* Quick Release Couplings	2 - 5
Lubricants - Health and Safety	
Hygiene	3 - 1
Storage	3 - 1
Waste Disposal	3 - 1
Handling	3 - 1
First Aid	3 - 1
Spillage	3 - 1
Fires	3 - 1
Hydraulic Fluid Quality	
Effects of Contamination	4 - 1
Cleaning Operation	4 - 1
Contaminant standards	4 - 1
* Filters	4 - 1
Hydraulic Oils, Filtering and Cooling	4 - 2
Torque Settings	5 - 1
* Sealing and Retaining Compounds	5 - 2
Rams	
JCB Typical Ram	
Dismantling and Assembly	6 - 1
Proprietary Rams	
Dismantling and Assembly	6 - 3