

780 CK LOADER BACKHOE TABLE OF CONTENTS

SERIES/SECTION	SECTION NO.	FORM NO.
10 SERIES - GENERAL		
Maintenance and Lubrication	13	9-71435
General Engine Specifications	1010	9-80675
Detailed Engine Specifications	1023	9-78646
20 SERIES - ENGINE		
General Engine Service and Removal	21	9-71435
Engine Air Cleaner	24	9-71435
Air Cleaner Installation, Turbocharged Engine	24, Sup. 1	9-71435
Engine Diagnosis	2001	9-76365
Engine Tuneup	2002	9-76379
Cylinder Head, Valve Train, and Camshaft	2015	9-76166
Cylinder Block, Sleeves, Pistons and Rods	2025	9-76176
Crankshaft, Main Bearings, Flywheel and Oil Seal Replacement	2035	9-76187
Lubrication System	2047	9-78667
Cooling System	2055	9-76337
Turbocharger Failure Analysis	2565	9-78235
30 SERIES - FUEL SYSTEM		
Electric Fuel Pump	34	9-71435
Fuel Tank and Fuel Lines	36	9-71435
Fuel System and Filters	3010	9-75297
Robert Bosch Fuel Injection Pump	3012	9-74937
Roosa Master Fuel Injectors	3013	9-74959
40 SERIES - HYDRAULICS		
Hydraulic System Flowmeter Tests and Pressure Checks (All Machines)	40	9-71435
Loader/Backhoe Hydraulic System	41	9-71435
Loader Hydraulic Diagram After SN 5500550, Backhoe Hydraulic Diagram and Installations, Loader Control Valve, Dipper Extension Cylinder	41, Sup. 1	9-71435
Backhoe Control Valve	44	9-71435
Backhoe Basic Hydraulic Installation and Control Levers .44, Sup. 1	44, Sup. 1	9-71435
Hydra-Guide	47	9-71435
50 SERIES - STEERING		
Steering Hydraulic System	51	9-71435
Front Axle	58	9-71435
60 SERIES - POWER TRAIN		
Clark Transmission Maintenance and Service Manual, HR28000 Series, 2 Speed		SM HR282
Clark Transmission Maintenance and Service Manual Supplement, To Be Used in Conjunction with the HR28000 Series, 2 Speed Maintenance and Service Manual		SMS 282

SERIES/SECTION	SECTION NO.	FORM NO.
60 SERIES - POWER TRAIN (CONT'D.)		
General Transmission Service and Removal	63	9-71435
Differential, Planetaries and Drive Shaft	67	9-71435
Differential and Planetaries (Tractor SN 5500354 and After, Except 5500426 thru 5500439)	67, Sup. 1	9-71435
70 SERIES - BRAKES		
Brake System Diagram/Operation	71	9-71435
Brake System	72	9-71435
80 SERIES - ELECTRICAL		
Electrical System	82	9-71435
Wiring Diagram, Trouble Shooting the Starting and Charging Circuits, A15485 and R26136 Starters, Ether Injector Starting Aid	82, Sup. 1	9-71435
90 SERIES - MOUNTED EQUIPMENT		
Loader	92	9-71435
Loader Exploded Views, Return-To-Dig, Anti-Rollback, SN 5500550 and After	92, Sup. 1	9-71435
Backhoe	93	9-71435
Boom Lock, Dipper Extension, Hydraulic Installations with SN 5500550 and After, Backhoe Controls with SN 5500166 and After and SN 5500155 and 5500162	93, Sup. 1	9-71435
Rollover Protective Structure	99	9-71435