



[Click here to get the complete manual](#)




- 1. Trim along dashed line.
- 2. Slide into pocket on Binder Spine.

TYPE 1-4




- 1. Trim along dashed line.
- 2. Slide into pocket on Binder Spine.

TYPE 1-4



- 1. Trim along dashed line.
- 2. Slide into pocket on Binder Spine.

TYPE 1-4



- 1. Trim along dashed line.
- 2. Slide into pocket on Binder Spine.

TYPE 1-4

## 350B CRAWLER

### TABLE OF CONTENTS

| SERIES/SECTION                                             | SECTION NO. | FORM NO. |
|------------------------------------------------------------|-------------|----------|
| 10 SERIES - GENERAL                                        |             |          |
| General Engine Specifications - 188 Engine .....           | 1010        | 9-46321  |
| Decals and Repainting .....                                | 1012        | 9-67880  |
| Detailed Engine Specifications - 188 Engine .....          | 1027        | 9-78675  |
| Maintenance and Lubrication .....                          | 1050        | 9-67880  |
| Torque Charts .....                                        | 1051        | 9-67880  |
| Noise Control .....                                        | 1052        | 9-67880  |
| 20 SERIES - ENGINES                                        |             |          |
| Engine Diagnosis .....                                     | 2001        | 9-78875  |
| Engine Tune-Up .....                                       | 2002        | 9-78825  |
| Cylinder Head, Valve Train, and Camshaft .....             | 2015        | 9-78836  |
| Cylinder Block, Sleeves, Pistons, and Rods .....           | 2025        | 9-78855  |
| Crankshaft, Bearings, Flywheel, and Oil Seals .....        | 2035        | 9-78866  |
| Oil Pump .....                                             | 2045        | 9-78885  |
| General Engine Information .....                           | 2050        | 9-67880  |
| Air Cleaner and Muffler .....                              | 2051        | 9-67880  |
| Ether Injection System .....                               | 2053        | 9-67880  |
| Cooling System .....                                       | 2055        | 9-78816  |
| Engine Lubrication .....                                   | 2555        | 9-78985  |
| 30 SERIES - FUEL SYSTEM                                    |             |          |
| Fuel Filters .....                                         | 3010        | 9-78785  |
| Fuel Injection Pump .....                                  | 3012        | 9-78795  |
| Fuel Injectors .....                                       | 3013        | 9-78806  |
| Engine Controls, Fuel Lines, and Fuel Tank .....           | 3052        | 9-67880  |
| 40 SERIES - ELECTRICAL SYSTEM                              |             |          |
| Electrical System Specifications and Troubleshooting ..... | 4002        | 9-67880  |
| Wiring Diagram .....                                       | 4003        | 9-67880  |
| Gauges .....                                               | 4004        | 9-67880  |
| Battery .....                                              | 4005        | 9-67880  |
| Starter and Starter Solenoid .....                         | 4006        | 9-67880  |
| Alternator .....                                           | 4007        | 9-67880  |
| Electrical Accessories .....                               | 4015        | 9-67880  |
| 50 SERIES - TRACK SYSTEM                                   |             |          |
| Track and Track Frame .....                                | 5506        | 9-67880  |
| Idler, Track Adjuster, and Recoil Housing .....            | 5508        | 9-67880  |
| Sprocket .....                                             | 5509        | 9-67880  |
| Carrier Rollers .....                                      | 5510        | 9-67880  |
| Track Rollers .....                                        | 5511        | 9-67880  |

**Reprinted**

| SERIES/SECTION                                  | SECTION NO. | FORM NO. |
|-------------------------------------------------|-------------|----------|
| 60 SERIES - POWER TRAIN                         |             |          |
| Power Shuttle Troubleshooting and Testing ..... | 6202        | 9-67880  |
| Power Shuttle and Torque Converter .....        | 6210        | 9-67880  |
| Transmission and Differential .....             | 6214        | 9-67881  |
| Universal Joint Coupling .....                  | 6222        | 9-67880  |
| Final Drives .....                              | 6225        | 9-67880  |
| Power Takeoff .....                             | 6231        | 9-67880  |
| 70 SERIES - BRAKES                              |             |          |
| Brakes .....                                    | 7001        | 9-67880  |
| 80 SERIES - HYDRAULIC SYSTEM                    |             |          |
| General Hydraulic System Information .....      | 8002        | 9-67880  |
| Hydraulic Pump .....                            | 8005        | 9-67880  |
| Equipment Control Valve .....                   | 8007        | 9-67880  |
| Cylinders .....                                 | 8090        | 9-67880  |
| Backhoe Control Valve .....                     | 8107        | 9-67880  |
| 90 SERIES - MOUNTED EQUIPMENT                   |             |          |
| Loader .....                                    | 9010        | 9-67880  |
| Dozer Blade and Frame .....                     | 9020        | 9-67880  |
| Ripper .....                                    | 9031        | 9-67880  |
| ROPS Canopy .....                               | 9061        | 9-67880  |
| Backhoe .....                                   | 9100        | 9-67880  |
| Winch .....                                     | 9300        | 9-67880  |