

[Click here to get the complete manual](#)

**650M**  
**Tier 4B (final)**  
**Crawler Dozer**  
*PIN NHC100263 and above*

**SERVICE MANUAL**

**Part number 48153338**

1<sup>st</sup> edition English

April 2018





## **SERVICE MANUAL**

**650M Long Track (LT) - Tier 4B (final) [NHC100263 - ]**  
**650M Wide Track (WT) / Low Ground Pressure (LGP) - Tier 4B (final)**  
**[NHC100263 - ]**

## Link Product / Engine

---

| Product                                                                                 | Market Product | Engine         |
|-----------------------------------------------------------------------------------------|----------------|----------------|
| 650M Long Track (LT) - Tier 4B<br>(final) [NHC100263 - ]                                | North America  | F5HFL463D*G805 |
| 650M Wide Track (WT) / Low<br>Ground Pressure (LGP) - Tier 4B<br>(final) [NHC100263 - ] | North America  | F5HFL463D*G805 |

# Contents

---

## INTRODUCTION

|                                                                 |       |
|-----------------------------------------------------------------|-------|
| Maintenance .....                                               | 00    |
| [00.150] Start-up.....                                          | 00.1  |
| [00.AAA] Maintenance generic sub-group.....                     | 00.2  |
| Engine.....                                                     | 10    |
| [10.001] Engine and crankcase .....                             | 10.1  |
| [10.216] Fuel tanks .....                                       | 10.2  |
| [10.206] Fuel filters .....                                     | 10.3  |
| [10.218] Fuel injection system.....                             | 10.4  |
| [10.202] Air cleaners and lines .....                           | 10.5  |
| [10.250] Turbocharger and lines.....                            | 10.6  |
| [10.501] Exhaust Gas Recirculation (EGR) exhaust treatment..... | 10.7  |
| [10.400] Engine cooling system .....                            | 10.8  |
| [10.414] Fan and drive .....                                    | 10.9  |
| [10.310] Aftercooler.....                                       | 10.10 |
| [10.304] Engine lubrication system.....                         | 10.11 |
| Power coupling.....                                             | 19    |
| [19.100] Drive shaft.....                                       | 19.1  |
| Hydrostatic drive.....                                          | 29    |
| [29.218] Pump and motor components.....                         | 29.1  |
| Brakes and controls .....                                       | 33    |
| [33.110] Parking brake or parking lock .....                    | 33.1  |
| Hydraulic systems.....                                          | 35    |
| [35.000] Hydraulic systems.....                                 | 35.1  |
| [35.300] Reservoir, cooler, and filters.....                    | 35.2  |
| [35.106] Variable displacement pump .....                       | 35.3  |

|                                                                  |           |
|------------------------------------------------------------------|-----------|
| [35.359] Main control valve .....                                | 35.4      |
| [35.741] Dozer blade cylinders .....                             | 35.5      |
| <b>Hitches, drawbars, and implement couplings.....</b>           | <b>37</b> |
| [37.100] Drawbars and towing hitches .....                       | 37.1      |
| <b>Tracks and track suspension .....</b>                         | <b>48</b> |
| [48.130] Track frame and driving wheels .....                    | 48.1      |
| [48.100] Tracks .....                                            | 48.2      |
| [48.134] Track tension units .....                               | 48.3      |
| [48.138] Track rollers .....                                     | 48.4      |
| [48.140] Dropbox and final drive .....                           | 48.5      |
| <b>Cab climate control .....</b>                                 | <b>50</b> |
| [50.104] Ventilation .....                                       | 50.1      |
| [50.200] Air conditioning .....                                  | 50.2      |
| <b>Electrical systems .....</b>                                  | <b>55</b> |
| [55.000] Electrical system .....                                 | 55.1      |
| [55.100] Harnesses and connectors.....                           | 55.2      |
| [55.015] Engine control system.....                              | 55.3      |
| [55.201] Engine starting system .....                            | 55.4      |
| [55.301] Alternator.....                                         | 55.5      |
| [55.302] Battery.....                                            | 55.6      |
| [55.202] Cold start aid .....                                    | 55.7      |
| [55.989] Exhaust Gas Recirculation (EGR) electrical system ..... | 55.8      |
| [55.640] Electronic modules .....                                | 55.9      |
| [55.404] External lighting .....                                 | 55.10     |
| [55.408] Warning indicators, alarms, and instruments .....       | 55.11     |
| [55.991] Telematics .....                                        | 55.12     |
| [55.DTC] FAULT CODES.....                                        | 55.13     |
| <b>Lubrication system.....</b>                                   | <b>71</b> |

|                                                    |           |
|----------------------------------------------------|-----------|
| [71.460] Grease lubrication system .....           | 71.1      |
| <b>Dozer blade and arm.....</b>                    | <b>86</b> |
| [86.110] Dozer blade .....                         | 86.1      |
| [86.124] Dozer pushbeams and struts .....          | 86.2      |
| <b>Tools .....</b>                                 | <b>89</b> |
| [89.128] Ripper assembly .....                     | 89.1      |
| <b>Platform, cab, bodywork, and decals.....</b>    | <b>90</b> |
| [90.150] Cab.....                                  | 90.1      |
| [90.151] Cab interior.....                         | 90.2      |
| [90.154] Cab doors and hatches .....               | 90.3      |
| [90.110] Operator platform less cab .....          | 90.4      |
| [90.114] Operator protections .....                | 90.5      |
| [90.120] Mechanically-adjusted operator seat.....  | 90.6      |
| [90.124] Pneumatically-adjusted operator seat..... | 90.7      |
| [90.100] Engine hood and panels .....              | 90.8      |