

# 1450B AND 1455B CRAWLER TABLE OF CONTENTS AND SERVICE MANUAL INTRODUCTION

## Table of Contents

DIVISION/SECTION	SECTION NO.	FORM NO.
<b>10 SERIES - GENERAL</b>		
General Engine Specifications - 504BDT .....	1010	8-27710
Decals and Repainting.....	1012	9-67891
Detailed Engine Specifications - 504BDT.....	1020	8-27760
Maintenance and Lubrication .....	1050	9-67891
Torque Charts .....	1051	9-67890
Noise Control .....	1052	9-67890
<b>20 SERIES - ENGINE</b>		
Engine Diagnosis .....	2001	9-76365
Engine Tune-up.....	2002	9-76379
Cylinder Head, Valve Train and Camshaft .....	2015	9-76166
Cylinder Block, Sleeves, Pistons and Rods .....	2025	9-76176
Crankshaft, Main Bearings, Flywheel and Oil Seals .....	2035	9-76187
Lubrication System.....	2046	8-22780
General Engine Information and Radiator.....	2050	9-67890
Air Cleaner.....	2051	9-67891
Ether Injection .....	2053	9-67891
Cooling System.....	2055	9-76337
Turbocharger Removal and Installation.....	2065	9-67890
Reconditioning Engine Cylinder Block.....	2290	8-21170
Turbocharger Failure Analysis .....	2565	9-78235
<b>30 SERIES - FUEL SYSTEM</b>		
Fuel System and Filter .....	3010	9-75297
Robert Bosch Fuel Injection Pumps.....	3012	9-74937
Roosa Master Fuel Injectors.....	3013	9-74959
Fuel Lines and Fuel Tank .....	3052	9-67890
<b>40 SERIES - ELECTRICAL SYSTEM</b>		
Electrical System Specifications and Troubleshooting .....	4002	9-67891
Wiring Diagram .....	4003	9-67890
Gauges.....	4004	9-67890
Batteries .....	4005	9-67891
Starter and Starter Solenoid.....	4006	9-67891
Alternator .....	4007	9-67891
Electrical Accessories .....	4015	9-67890
<b>50 SERIES - TRACK SYSTEM</b>		
Case Lubricated Track.....	5504	8-42190
Track and Track Frame.....	5506	9-67891
Idler, Track Adjuster and Recoil Housing.....	5508	9-67891
Sprocket .....	5509	9-67890
Carrier Roller .....	5510	9-67891
Track Rollers .....	5511	9-67891

DIVISION/SECTION	SECTION NO.	FORM NO.
<b>60 SERIES - POWER TRAIN</b>		
General Transmission Information.....	6002	9-67891
Transmission Diagrams and Operation.....	6003	9-67891
Charging Pump.....	6005	9-67891
Transmission Control Valve.....	6007	9-67891
Torque Converter.....	6010	9-67891
Transmission.....	6016	9-67891
Final Drive for 1450B Loader.....	6017	9-67891
Final Drive Planetary.....	6018	8-15510
Transmission Controls.....	6019	8-67890
Drive Shaft.....	6021	9-67890
<b>70 SERIES - BRAKES</b>		
Brakes.....	7001	9-67891
<b>80 SERIES - HYDRAULIC SYSTEM</b>		
General Hydraulic System Information.....	8002	9-67891
Hydraulic Pump.....	8005	9-67891
Equipment Control Valve.....	8007	9-67891
Selector Valve.....	8021	9-67890
Cylinders.....	8090	9-67891
<b>90 SERIES - MOUNTED EQUIPMENT</b>		
Air Conditioning Troubleshooting and System Checks.....	9002	8-41280
Air Conditioning System.....	9003	9-67890
Loader.....	9010	9-67891
Blade.....	9020	9-67891
Ripper.....	9031	9-67891
ROPS Canopy.....	9061	9-67891
Winch.....	9300	9-67891