

[Click here to get the complete manual](#)

# **SERVICE MANUAL**

**TRACTOR, FULL TRACKED  
NSN: 2410-01-254-1667  
MODEL MC1150E**

**JI CASE COMPANY  
RACINE WI 53404  
Burl 8-72810**



# MC1150E Crawler TABLE OF CONTENTS

| SERIES/SECTION   | SECTION NO. | FORM NO. |
|--|-------------|----------|
| <b>1 GENERAL</b>   |             |          |
| Safety Rules, Service Manual Introduction, and Torque  |             |          |
| Specifications .....   | 1001        | 8-42850  |
| General Engine Specifications - 1150E .....  | 1010        | 8-28720  |
| Detailed Engine Specifications .....   | 1024        | 8-26061  |
| General Machine Specifications .....   | 1210        | 8-42850  |
| Maintenance and Lubrication .....  | 1212        | 8-42850  |
| Power Train Specifications .....   | 1260        | 8-42850  |
| Brake Specifications .....   | 1270        | 8-42850  |
| Hydraulic System Specifications .....  | 1280        | 8-42850  |
| <b>2 ENGINE</b>  |             |          |
| Engine and Radiator Removal and Installation .....   | 2000        | 8-42850  |
| Engine Accessories .....   | 2001        | 8-42850  |
| Engine Stall Tests .....   | 2002        | 8-42850  |
| Cylinder Head and Valve Train - 1150E .....  | 2415        | 8-26071  |
| Cylinder Block, Crankshaft, Pistons, Rods, sleeves, Camshaft,<br>and Seals - 1150E .....                               | 2425        | 8-26081  |
| Lubrication System - Oil Pan, Oil Pump, Oil Cooler,<br>and Oil Filter Housing - 1150E .....                            | 2445        | 8-26091  |
| Cooling System - Thermostat, Water Pump, Fan Pulley,<br>and Belt Tensioner - 1150E .....                               | 2455        | 8-26101  |
| Turbocharger - 1150E .....   | 2465        | 8-26110  |
| Turbocharger Failure Analysis .....  | 2565        | 9-78235  |
| <b>3 FUEL SYSTEM</b>   |             |          |
| Fuel Lines, Fuel Tank, and Engine Controls .....   | 3001        | 8-42850  |
| Fuel System and Filters - 1150E .....  | 3410        | 8-26131  |
| Injection Pump - Pump Drive Gear, Timing Pin,<br>Fuel Shut-Off Solenoid, Primer Pump, and Pump<br>Timing - 1150E ..... | 3412        | 8-26141  |
| Fuel Injectors - 1150E .....   | 3413        | 8-26150  |
| <b>4 ELECTRICAL SYSTEM</b>   |             |          |
| Removal and Installation of Electrical Components .....  | 4000        | 8-42850  |
| Electrical System Specifications and Troubleshooting .....   | 4002        | 8-42850  |
| Electrical Schematics .....  | 4003        | 8-42850  |
| Indicators and Gauges .....  | 4004        | 8-42850  |
| Batteries .....  | 4005        | 8-44360  |
| 24 Volt Delco-Remy Starter and Starter Solenoid .....  | 4009        | 8-42850  |
| 24 Volt Alternator .....   | 4019        | 8-42850  |
| <b>5 TRACK</b>   |             |          |
| Removal and Installation of Track Components .....   | 5500        | 8-42850  |
| Case Lubricated Track .....  | 5504        | 8-42190  |
| Track Frame and Suspension .....   | 5506        | 8-42850  |
| Track Adjuster .....   | 5507        | 8-42850  |
| Idler .....  | 5508        | 8-42850  |
| Sprocket .....   | 5509        | 8-41280  |
| Carrier Roller .....   | 5510        | 8-42850  |
| Track Roller .....   | 5511        | 8-42850  |



**6 POWER TRAIN**

|  |      |         |
|--|------|---------|
| Transmission Maintenance and Troubleshooting ..... | 6002 | 8-42350 |
| Transmission Diagrams and Operation .....          | 6003 | 8-41280 |
| Charging Pump .....                                | 6005 | 9-67861 |
| Transmission Control Valve .....                   | 6007 | 8-41280 |
| Torque Converter .....                             | 6010 | 8-42850 |
| Transmission .....                                 | 6016 | 8-41280 |
| Final Drive .....                                  | 6017 | 8-42850 |
| Transmission Controls .....                        | 6018 | 8-42850 |
| Drive Shaft .....                                  | 6021 | 8-42850 |

**7 BRAKES**

|              |      |         |
|--------------|------|---------|
| Brakes ..... | 7001 | 8-41280 |
|--------------|------|---------|

**8 HYDRAULICS**

|   |      |         |
|---|------|---------|
| Hydraulic System Specifications, Diagrams, Maintenance,<br>Troubleshooting, and Pressure Checks ..... | 8002 | 8-42850 |
| Cleaning the Hydraulic System .....   | 8003 | 8-41280 |
| Pump .....  | 8005 | 8-42850 |
| Equipment Control Valve .....   | 8007 | 8-42850 |
| Cylinders .....   | 8090 | 8-42850 |

**9 MOUNTED EQUIPMENT**

|                                     |      |         |
|-------------------------------------|------|---------|
| Dozer Blade .....                   | 9020 | 8-42850 |
| ROPS Cab .....                      | 9061 | 8-42850 |
| Operators Seat and Seat Belts ..... | 9064 | 8-42850 |
| Suspension Seat .....               | 9065 | 8-42850 |
| Winch .....                         | 9300 | 8-41280 |