

[Click here to get the complete manual](#)

SERVICE MANUAL
EXCAVATORS
9050B

7-44700

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

SERVICE MANUAL
EXCAVATORS
9050B

7-44700

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

SERVICE MANUAL
EXCAVATORS
9050B

7-44700

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

SERVICE MANUAL
EXCAVATORS
9050B

7-44700

1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

9050 Excavator Service Manual

Table of Contents

Description	Section No.	Form No.
General	Tab 1	
Section Index - General		7-45290
Standard Torque Specifications for 9000 Series Excavators	1001	7-44790
Fluids and Lubricants	1002	7-45220
Engines	Tab 2	
Section Index - Engines		7-45300
Engine Specification Details	2000	7-46340
Engine Removal and Installation	2001	7-45310
Radiator Removal and Installation	2002	7-45320
Mitsubishi Motors Shop Manual		97841-02003
Fuel System	Tab 3	
Section Index - Fuel System		7-45330
See Mitsubishi Motors Shop Manual in Tab 2		
Electrical	Tab 4	
Section Index - Electrical		7-45340
Electrical Specifications and Troubleshooting	4001	7-45230
Electrical Schematic Foldout	In Rear Pocket	7-45260
Batteries	4002	7-44950
Systems Display Panel	4005	7-44980
Starter and Starter Solenoid	See Mitsubishi Motors Shop Manual in Tab 2	
Alternator	See Mitsubishi Motors Shop Manual in Tab 2	
Tracks	Tab 5	
Section Index - Tracks		7-45350
Troubleshooting the Track System	5001	7-44830
Tracks, Rollers, and Idlers	5002	7-44880
Power Train	Tab 6	
Section Index - Power Train		7-45370
Troubleshooting - See Section 8001		
Drive Motor and Final Drive Transmission	6000	7-45360
Hydraulics	Tab 8	
Section Index - Hydraulics		7-45380
Cleaning the Hydraulic System	8000	7-45050
Hydraulic Specifications, Troubleshooting, and Pressure Checks	8001	7-45240
Hydraulic Schematic Foldout	In Rear Pocket	7-45260
Main Hydraulic Pump	8002	7-45480

Reprinted

9050 Excavator Service Manual

Table of Contents

Description	Section No.	Form No.
Pilot Control Circuit Pump	8003	7-46350
Hydraulic Swivel	8004	7-45390
Main Control Valve	8005	7-45400
Remote Control Valves	8006	7-45410
Solenoid Valves	8007	7-45420
Swing Motor and Swing Reduction Gear Box	8008	7-45430
Cylinders	8009	7-45440
Cushion Control Valve	8010	7-45450
Mounted Equipment	Tab 9	
Section Index - Mounted Equipment		7-45460
Pedals and Levers	9001	7-45250
Turntable Bearing	9003	7-46220
Boom and Arm	9004	7-45470
Seat and Seat Belts	9006	7-45170
Electrical Schematic Foldout	In Rear Pocket	7-45260
Hydraulic Schematic Foldout	In Rear Pocket	7-45260