

[Click here to get the complete manual](#)

CK25-CK28 Crawler Excavators

Table of contents

DIVISION/SECTION	SECTION N°	FORM N°
1. GENERAL		
Safety, General Information and Torque Specifications	1001	7-55741GB
General specifications	1002	7-37930GB
2. ENGINE		
Engine Removal and Installation	2002	7-37940GB
Engine Disassembly/Assembly, Lubrication System, Cooling System and Fuel System	2010	7-37950GB
4. ELECTRICAL		
Electrical Troubleshooting and Schematics.....	4001	7-37960GB
Alternator	4002	7-37980GB
Starter Motor.....	4003	7-37970GB
5. UNDERCARRIAGE		
Tracks, Rollers and Idlers	5002	7-37990GB
6. POWER TRAIN		
Travel Motor and Reduction	6002	7-38000GB
Swing Reduction Gear.....	6003	7-38150GB
7. UNDERCARRIAGE HYDRAULICS		
Hydraulic Swivel	7004	7-38010GB
8. UPPERSSTRUCTURE HYDRAULICS		
Pressure setting, Troubleshooting, Hydraulic Schematics	8001	7-38020GB
Hydraulic Reservoir	8010	7-38030GB
Main hydraulic Pump	8020	7-38040GB
Hydraulic Pilot Pump	8021	7-38130GB
Attachment valve	8032	7-38050GB
Swing and offset cylinder flow selector valve	8035	7-38060GB
Pressure Limiter and Flow Cut-Off Valve	8036	7-38140GB
Swing Motor (CK25)	8037	7-56660GB
Swing Motor (CK28)	8037	7-37920GB
Hand Control Valve.....	8050	7-38120GB
Attachment cylinders	8081	7-38070GB
9. UPPERSSTRUCTURE/ATTACHMENTS		
Upperstructure and Turntable Bearing	9001	7-38080GB
Boom, Dipper, Bucket and Dozer Blade.....	9002	7-38090GB
Pedals and Levers	9003	7-38100GB
Operator's Cab and Canopy	9004	7-38110GB