

[Click here to get the complete manual](#)

## CK36-CK50 Excavators

### Table of contents

DIVISION/SECTION	SECTION NO	FORM NO
<b>1. GENERAL</b>		
Safety, General Information and Torque Specifications .....	1001 .....	7-55741GB
General specifications .....	1002 .....	7-38190GB
<b>2. ENGINE</b>		
Engine Removal and Installation .....	2002 .....	7-38200GB
Engine Disassembly/Assembly, Lubrication System, Cooling System and Fuel System .....	2010 .....	7-38210GB
<b>4. ELECTRICAL</b>		
Electrical Troubleshooting and Schematics .....	4001 .....	7-38220GB
Alternator .....	4002 .....	7-38230GB
Starter Motor .....	4003 .....	7-38240GB
<b>5. UNDERCARRIAGE</b>		
Tracks, Rollers and Idlers .....	5002 .....	7-38250GB
<b>6. POWER TRAIN</b>		
Travel Motor and Reduction .....	6002 .....	7-38260GB
Swing Reduction Gear .....	6003 .....	7-38270GB
<b>7. UNDERCARRIAGE HYDRAULICS</b>		
Hydraulic Swivel .....	7004 .....	7-38010GB
<b>8. UPPERSTRUCTURE HYDRAULICS</b>		
Pressure setting, Troubleshooting, Hydraulic Schematics .....	8001 .....	7-38280GB
Hydraulic Reservoir .....	8010 .....	7-38290GB
Hydraulic Pump .....	8020 .....	7-38300GB
Hydraulic Pilot Pump .....	8021 .....	7-38310GB
Attachment Valve .....	8032 .....	7-38320GB
Swing and offset cylinder flow selector valve .....	8035 .....	7-38060GB
Pressure Limiter and Flow Cut-Off Valve .....	8036 .....	7-38140GB
Swing Motor .....	8037 .....	7-38330GB
Hand Control Valve .....	8050 .....	7-38120GB
Attachment cylinders .....	8081 .....	7-38340GB
<b>9. UPPERSTRUCTURE/ATTACHMENTS</b>		
Upperstructure and Turntable Bearing .....	9001 .....	7-38350GB
Boom, Dipper, Bucket and Dozer Blade .....	9002 .....	7-38360GB
Pedals and Levers .....	9003 .....	7-38500GB
Operator's Cab and Canopy .....	9004 .....	7-38110GB