

[Click here to get the complete manual](#)

# **Mini Excavators**

## **CX16B and CX18B**

### **SERVICE MANUAL**



## TO THE READER

- This manual has been written for a skilled technician, in order to give him the information necessary to repair this machine.
- Read this manual carefully for correct information about repair procedures.
- For any question or comment, or in case you notice a mistake in this manual content, please contact:

CNH FRANCE S.A.  
18, place des Nymphéas ZI Paris Nord II  
93420 Villepinte France

---

---

## ADDITIONAL REFERENCE MANUALS

- In addition to this Workshop Manual, refer also to the following:
  - Operation and maintenance instruction manual
  - Spare parts catalog

---

---

## DESCRIPTION OF THE COMPLETE WORKSHOP MANUAL

- The complete repair manual consists of two volumes:  
  
***CX16B and CX18B***  
**Workshop Manual "Excavator"**
- "Excavator" and "Engine" Workshop Manuals contain the technical information necessary for

machine/engine service and repair, service equipment, information on maintenance standards, remove and install procedures, disassembly and assembly procedures.

- The complete Workshop Manual for the excavator models ***CX16B and CX18B*** consists of the following volumes identified by print number as shown herebelow:

VOLUME	MACHINE TYPE	PRINT NO.
- Workshop Manual - "Excavator"	<i>CX16B</i> <i>CX18B</i>	9-88670