

[Click here to get the complete manual](#)

DV213
Tier 3
Vibratory Roller

SERVICE MANUAL

Part number 47703722

2nd edition English

September 2015

Replaces part number 84287246A

CASE
CONSTRUCTION



SERVICE MANUAL

DV213

Contents

INTRODUCTION

Machine completion and equipment	05
[05.102] Machine completion	05.1
Engine	10
[10.001] Engine and crankcase	10.1
[10.400] Engine cooling system	10.2
Hydrostatic drive	29
[29.218] Pump and motor components	29.1
Hydraulic systems	35
[35.000] Hydraulic systems	35.1
[35.353] Hydraulic travel system	35.2
[35.995] Compaction/vibration hydraulic system	35.3
[35.500] Radiator cleaning system	35.4
[35.304] Combination pump units	35.5
Frames and ballasting	39
[39.500] Vibratory roller	39.1
[39.100] Frame	39.2
Steering	41
[41.101] Steering control	41.1
[41.206] Pump	41.2
[41.216] Cylinders	41.3
Wheels	44
[44.160] Compaction drums	44.1
Cab climate control	50
[50.100] Heating	50.1

Electrical systems	55
[55.000] Electrical system	55.1
[55.100] Harnesses and connectors.....	55.2
[55.201] Engine starting system	55.3
[55.301] Alternator.....	55.4
[55.302] Battery.....	55.5
[55.408] Warning indicators, alarms, and instruments	55.6
[55.019] Hydrostatic drive control system	55.7
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system.....	55.8
[55.518] Wiper and washer system.....	55.9
[55.512] Cab controls.....	55.10
Platform, cab, bodywork, and decals	90
[90.120] Mechanically-adjusted operator seat.....	90.1
[90.105] Machine shields and guards	90.2