

[Click here to get the complete manual](#)

SV208
SV210
SV212
SV216
Tier 3
Vibratory Roller

SERVICE MANUAL

Part number 47688018
2nd edition English
June 2014
Replaces part number 87480985NA

CASE
CONSTRUCTION

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.400] Engine cooling system	10.2
Power coupling.....	19
[19.110] Flywheel damper	19.1
Hydrostatic drive.....	29
[29.218] Pump and motor components.....	29.1
[29.202] Hydrostatic transmission	29.2
Brakes and controls	33
[33.110] Parking brake or parking lock	33.1
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.995] Compaction/vibration hydraulic system	35.3
Frames and ballasting	39
[39.100] Frame	39.1
[39.500] Vibratory roller.....	39.2
Steering.....	41
[41.216] Cylinders	41.1
Wheels	44
[44.520] Rear wheels.....	44.1
[44.160] Compaction drums	44.2
Cab climate control	50
[50.200] Air conditioning	50.1

Electrical systems	55
[55.011] Fuel tank system	55.1
[55.036] Hydraulic system control	55.2
[55.100] Harnesses and connectors.....	55.3
[55.302] Battery.....	55.4
[55.512] Cab controls.....	55.5
[55.408] Warning indicators, alarms, and instruments	55.6
[55.DTC] FAULT CODES.....	55.7