

[Click here to get the complete manual](#)

**621G
721G
Stage IV
Wheel Loader**

SERVICE MANUAL

Part number 51428211
English
November 2017
© 2017 CNH Industrial Italia S.p.A. All Rights Reserved.

CASE
CONSTRUCTION



SERVICE MANUAL

621G WHEEL LOADER XR-EH, NEW CAB TIER4B MULTIP., 621G WHEEL LOADER XR-EH, NEW CAB TIER4B, 621G WHEEL LOADER XT-EH, NEW CAB TIER4B, 621G WHEEL LOADER ZBAR-EH, NEW CAB TIER4B MULTIP., 621G WHEEL LOADER ZBAR-EH, NEW CAB TIER4B, 721G WHEEL LOADER XR EH, New Cab TIER 4B, 721G WHEEL LOADER XR-EH, NEW CAB TIER4B MULTIP., 721G WHEEL LOADER XT EH, New Cab TIER 4B, 721G WHEEL LOADER ZBAR EH, New Cab TIER 4B, 721G WHEEL LOADER ZBAR-EH, NEW CAB TIER4B MULTIP.

Link Product / Engine

Product	Market Product	Engine
621G WHEEL LOADER ZBAR-EH, NEW CAB TIER4B	Europe	F4HFE613W*B003
621G WHEEL LOADER ZBAR-EH, NEW CAB TIER4B MULTIP.	Europe	F4HFE613W*B003
621G WHEEL LOADER XT-EH, NEW CAB TIER4B	Europe	F4HFE613W*B003
621G WHEEL LOADER XR-EH, NEW CAB TIER4B	Europe	F4HFE613W*B003
621G WHEEL LOADER XR-EH, NEW CAB TIER4B MULTIP.	Europe	F4HFE613W*B003
721G WHEEL LOADER ZBAR EH, New Cab TIER 4B	Europe	F4HFE613T*B002
721G WHEEL LOADER ZBAR-EH, NEW CAB TIER4B MULTIP.	Europe	F4HFE613T*B002
721G WHEEL LOADER XT EH, New Cab TIER 4B	Europe	F4HFE613T*B002
721G WHEEL LOADER XR EH, New Cab TIER 4B	Europe	F4HFE613T*B002
721G WHEEL LOADER XR-EH, NEW CAB TIER4B MULTIP.	Europe	F4HFE613T*B002