# Click here to get the complete manual



# **SERVICE MANUAL**

BACKHOE LOADER

3CX

EN - 9813/7800 ISSUE 1 - 04/2017

This manual contains original instructions, verified by the manufacturer (or their authorized representative).

Copyright 2017 © JCB SERVICE

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

www.jcb.com

## **Foreword**

### The Operator's Manual

#### lack

You and others can be killed or seriously injured if you operate or maintain the machine without first studying the Operator's Manual. You must understand and follow the instructions in the Operator's Manual. If you do not understand anything, ask your employer or JCB dealer to explain it.

Do not operate the machine without an Operator's Manual, or if there is anything on the machine you do not understand.

Treat the Operator's Manual as part of the machine. Keep it clean and in good condition. Replace the Operator's Manual immediately if it is lost, damaged or becomes unreadable.

#### **Contents**

01 - Machine

03 - Attachments, Couplings and Load Handling

06 - Body and Framework

09 - Operator Station

12 - Heating, Ventilating and Air-Conditioning (HVAC)

15 - Engine

18 - Fuel and Exhaust System

21 - Cooling System

24 - Brake System

25 - Steering System

27 - Driveline


30 - Hydraulic System

33 - Electrical System

72 - Fasteners and Fixings

75 - Consumable Products

78 - After Sales







# **SERVICE MANUAL**

Volume 1

3CX

EN 9813/7800



# **SERVICE MANUAL**

Volume 2

**3CX** 

EN 9813/7800



## **SERVICE MANUAL**

Volume 3

3CX

EN 9813/7800



## **SERVICE MANUAL**

Volume 4

**3CX** 

EN 9813/7800