

[Click here to get the complete manual](#)

# TAKEUCHI®

## **Service manual**

# **WHEEL LOADER SERIES TW50**



ISSUE:08-08-07

*It is not allowed to duplicate this service manual, to use it otherwise or to leave it to a third party for evaluation without our explicit consent.*

**II. Table of Contents**

I.	Preface .....	3
II.	Table of Contents .....	5
<b>0</b>	<b>Introduction .....</b>	<b>9</b>
0.1	User Information on the Service Manual .....	10
0.2	Breakdown of Assembly Groups and Chapter Overview .....	11
0.3	Technical Description of the Wheel Loader .....	12
0.4	Safety Regulations for Work on the Wheel Loader .....	13
0.5	Safety Regulations in the Service Manual .....	14
0.6	Securing the Wheel Loader Prior to Beginning Work .....	15
0.7	Site Where Repair Work is Completed .....	16
0.8	International Measuring Units .....	17
0.9	Tightening Torques .....	18
0.9.1	Hose connections .....	18
0.9.2	Metric headless screws with standard threads .....	19
0.9.3	Metric headless screws with fine threads .....	19
0.9.4	RIPP screws with cheese head and hexagon socket .....	20
0.9.5	RIPP screws and nuts with cheese head and hexagon head .....	20
0.9.6	Self-locking screws and nuts with hexagon head .....	21
0.10	Positioning of Hydraulic Hose .....	22
<b>1</b>	<b>Front and Rear Carriage .....</b>	<b>23</b>
1.1	General Data .....	23
1.2	Front Carriage .....	23
1.3	Repairing the Front Carriage .....	24
1.4	Checking the Articulated Pendulum Joint .....	24
1.4.1	Faults in the articulated pendulum joint .....	24
1.4.2	Checking the assembly dimensions .....	25
1.4.3	Repairing the articulated pendulum joint .....	26
1.4.4	Disconnecting the front carriage from the rear carriage .....	28
1.4.5	Checking the pendulum joint .....	29
1.4.6	Checking the articulated joint .....	32
1.4.7	Reassembling the front and rear carriage .....	35
1.5	Repairing the Rear Carriage .....	38
1.5.1	Disassembling the engine hood .....	38
1.6	Welding and Preservation Work on the Wheel Loader .....	39
1.6.1	Welding .....	39
1.6.2	Preservation .....	40
1.7	Table of Figures .....	41
<b>2</b>	<b>Hoisting Gear and Hoisting Gear Hydraulics .....</b>	<b>43</b>
2.1	General Data .....	43
2.2	Operating Faults and Solutions .....	44
2.3	Maintenance Work .....	45
2.3.1	Greasing the hoisting gear .....	45
2.4	Repair Work on the Hoisting Gear and Hoisting Gear Hydraulics .....	46
2.4.1	Checking the hoisting gear .....	46
2.4.2	Disassembling the hoisting gear .....	48
2.4.3	Replacing the hoisting gear components .....	49
2.4.4	Replacing the hoisting gear hydraulic cylinders .....	50
2.4.5	Assembling the hoisting gear .....	51
2.5	Table of Figures .....	55

E-ARC00-BUCH-1211010-001-V1.2J.m

<b>3</b>	<b>Hydraulic System</b>	<b>57</b>
3.1	Breakdown of Assembly Groups	57
3.2	Technical data	57
3.3	Faults, Causes and Corrective Measures	58
3.4	Setting Instructions, Hydraulic System	63
3.4.1	Operating conditions for correct measurement results	64
3.4.2	Measuring and test instruments	65
3.4.3	Safety regulations, measurement and adjustment work	65
3.4.4	Environmental protection measures	65
3.5	Completing Adjustments	67
3.6	Completing Repairs	83
3.6.1	Completing repairs to the travel pump	83
3.6.2	Repairing the load pump	91
3.6.3	Repairs to the charge pump	94
3.6.4	Repairs to the pump set and travel pump	96
3.6.5	Repairing the travel motor	101
3.7	Repairing the Loading Circuit	107
3.7.1	Repairing the loading circuit control block	107
3.7.2		117
3.7.3	Repairing the hydraulic cylinders	117
3.7.4	Venting the loading circuit	128
3.8	Repairing the Steering Circuit	129
3.8.1	Repairing the steering unit	129
3.9	Repairing the Hydraulic Components	133
3.9.1	Repairing the inching valve	133
3.9.2	Repairing the differential lock control block	136
3.9.3	Checking the hydraulic oil cooler (combined cooler)	138
3.10	Checking the Hydraulic Circuit	141
3.10.1	Checking the hydraulic oil	141
3.10.2	Venting the hydraulic circuit	143
3.10.3	Operating the vacuum pump	145
3.10.4	Rinsing the hydraulic circuit	146
3.10.5	Replacing the hydraulic oil sort (to biological oil)	148
3.11	Table of Figures	151
<b>Appendix to Chapter 3: Hydraulic System Circuit Diagram</b>		<b>155</b>

E-ARS0-Buch-Standard-001VZ.fm

<b>4</b>	<b>Electrical System</b>	<b>159</b>
4.1	General Data	159
4.1.1	Overview of fuses	160
4.1.2	Overview of relays	161
4.1.3	Overview of lighting	161
4.1.4	Overview of switches	162
4.2	Operating Faults and Solutions	163
4.3	Service and Maintenance Work	164
4.3.1	Service and maintenance work on the battery	164
4.3.2	Checking the electrical system	164
4.4	Setting Instructions	165
4.5	Completing Repairs	166
4.5.1	Before beginning work	166
4.5.2	Repairing the control board	167
4.5.3	Repair work on the cab electrical system	169
4.5.4	Repairing the lighting system	172
4.5.5	Replacing the relay in the engine compartment	173
4.5.6	Replacing the hand brake switch	173
4.5.7	Replacing the brake light switch	173
4.6	Table of Figures	175
<b>Appendix to Chapter 4: Electric System Circuit Diagrams</b>		<b>177</b>
<b>5</b>	<b>Diesel Engine</b>	<b>189</b>
5.1	General Data	189
5.2	Technical Data	190
5.2.1	Diesel engine	190
5.2.2	Fuel	190
5.2.3	Engine oil	190
5.3	Faults, Causes, Solutions	191
5.3.1	Faults, causes and solutions related to the diesel engine	191
5.4	Maintenance Work on the Diesel Engine	192
5.4.1	Securing the wheel loader	192
5.4.2	Maintenance table	193
5.4.3	Checking and changing the engine oil	194
5.4.4	Visual inspection of the engine and checking the unit for leaks	195
5.4.5	Cleaning the engine cooling system (water cooling)	195
5.4.6	Cleaning the air filter	196
5.4.7	Checking the engine mount	197
5.4.8	Checking the fuel system	197
5.4.9	Venting the fuel system	198
5.4.10	Changing the fuel prefilter	198
5.4.11	Changing the fuel filter	199
5.4.12	Changing the engine oil filter	199
5.5	Setting Instructions	200
5.5.1	Checking the engine speed	200
5.5.2	Checking the fan belt	201
5.6	Completing Repairs	202
5.6.1	Replacing the accelerator cable	202
5.6.2	Replacing the exhaust system	203
5.7	Table of Figures	205

<b>7</b>	<b>Axles and Brakes</b> .....	<b>207</b>
7.1	General Data .....	207
7.1.1	Technical data .....	207
7.2	Operating Faults and Solutions .....	208
7.3	Maintenance Work, Axles and Drum Brake .....	209
7.3.1	Lubricants and filling quantities .....	209
7.3.2	Checking the oil level axle .....	209
7.3.3	Checking and changing the brake fluid .....	212
7.4	Completing Repairs .....	214
7.4.1	Securing the wheel loader for work on the axles .....	214
7.4.2	Replacing the cardan shaft .....	214
7.4.3	Replacing the front axle .....	215
7.4.4	Replacing the rear axle .....	216
7.4.5	Repair work on the drum brake .....	217
7.4.6	Disassembling the hydraulic drum brake .....	218
7.4.7	Assembling the hydraulic drum brake .....	222
7.4.8	Replacing the hand brake cable .....	227
7.4.9	Checking and replacing the axle transfer box .....	228
7.5	Table of Figures .....	233
<b>8</b>	<b>Operator's Cab</b> .....	<b>235</b>
8.1	Breakdown of Assembly Groups .....	235
8.2	Cleaning and Maintenance Work .....	235
8.3	Replacing the operator's seat .....	236
8.4	Table of Figures .....	237
<b>9</b>	<b>Table of Topics</b> .....	<b>239</b>