



NEW HOLLAND

W50TC
W60TC
W70TC
W80TC

Repair
manual

Repair manual

Print No. 87618246
English - Printed in Italy

W50TC
W60TC
W70TC
W80TC

TO READER

This manual has been printed for a skilful engineer to supply necessary technical information to carry out service operations on this machine.

CNH ITALIA S.p.A.

Viale delle Nazioni, 55
41100 MODENA - Italy

Read carefully this manual to collect correct information relevant to repair procedures.

For any question or remark, or in case of any error relevant the contents of this manual, please contact:

REFERENCES

Beyond this Repair Manual, also refer to documents hereunder listed:

- Operator's Manual
- Parts Catalogue

COMPLETE REPAIR MANUAL

The complete Repair Manual consists of two volumes:

- W50TC - W60TC - W70TC - W80TC Repair Manual "WHEEL LOADERS"
- W50TC - W60TC - W70TC - W80TC Repair Manual "Engine"

The Repair Manuals for "Wheel loaders" and "Engine" contain the necessary technical information to carry out service and repair on machine and on engine, necessary tools to carry out those operations and information on service standard, on procedures for connection, disconnection, disassembly and assembly of parts.

The complete Repair Manual which covers the loader models W50TC - W60TC - W70TC - W80TC consists of the following volumes, which can be identified through their print number as stated below:

VOLUME	MACHINE TYPE	PRINT NUMBER
Repair Manual - "Wheel loaders"	W50TC - W60TC - W70TC - W80TC	87618246
Repair Manual - "Engine"	W50TC - W60TC - W70TC - W80TC	87618255

TO PREVENT ACCIDENTS

The majority of accidents and injuries which occur in industry, on the farm, at home or on the road, are caused by the failure of some individual to follow simple and fundamental safety rules or precautions. For this reason **MOST ACCIDENTS CAN BE PREVENTED** by recognizing the real cause and taking the necessary precautions, before the accident occurs.

Regardless of the care used in design and construction of any type of equipment, there may be conditions that cannot be completely safeguarded against, without interfering with reasonable accessibility and efficient operation.

A careful operator and / or technician is the best insurance against accidents. The complete observance of one simple rule would prevent many thousands of serious injuries each year.

This rule is: Never attempt to clean, lubricate or adjust a machine while it is in motion.

WARNING

Before carrying out any maintenance operation, adjustment and or repair on machines equipped with attachments, controlled hydraulically or mechanically, make sure that the attachment is lowered and safely set on the ground. If it is necessary to have the equipment partially or fully raised to gain access to certain items, be sure the equipment is suitably supported by means other than the hydraulic lift cylinders, cable and /or mechanical device used for controlling the equipment.

CNH S.p.A.

Viale delle Nazioni, 55
41100 MODENA - Italy

All rights reserved. Reproduction of text or illustrations, in whole or in part, is strictly prohibited.

INDEX

SECTION 00 - INTRODUCTION

1. SAFETY INSTRUCTIONS	1
2. TECHNICAL SPECIFICATIONS	11

SECTION 10 - ENGINE

1. DIESEL ENGINE	1
2. FUEL SYSTEM	2

SECTION 25 - FRONT AXLES

1. REMOVAL AND INSTALLATION	1
2. DIMENSIONS	3
3. TECHNICAL SPECIFICATIONS	4
4. OIL CHANGE AND GREASING	7
5. DISASSEMBLY AND ASSEMBLY	8
5.1 BRAKE DISC ASSY	8
5.2 BRAKE CALIPER	15
5.3 EPICYCLIC REDUCTION GEAR ASSY (W50TC)	23
5.4 EPICYCLIC REDUCTION GEAR ASSY (W60TC, W70TC, W80TC)	27
5.5 WHEEL HUB ASSY (W50TC)	31
5.6 WHEEL HUB ASSY (W60TC, W70TC, W80TC)	40
5.7 WHEEL SHAFT ASSY (W60TC, W70TC, W80TC)	46
5.8 BRAKE AND WHEEL SHAFT ASSY (W60TC, W70TC, W80TC HIGH SPEED)	50
5.9 DIFFERENTIAL SUPPORT ASSY	58
5.10 DIFFERENTIAL ASSY	66
5.11 PINION ASSY	73
6. TROUBLESHOOTING	80
7. SPECIAL TOOLS	83

SECTION 27 - REAR AXLES

1. REMOVAL AND INSTALLATION	1
2. DIMENSIONS	3
3. TECHNICAL SPECIFICATIONS	7
4. OIL CHANGE AND GREASING	13
5. DISASSEMBLY AND ASSEMBLY	14
5.1 HYDRAULIC MOTOR ASSY TB150	14
5.2 HYDRAULIC MOTOR ASSY TB138.5 HIGH SPEED	17
5.3 TRANSMISSION BOX ASSY TB150	21
5.4 TRANSMISSION BOX ASSY TB138.5 HIGH SPEED	30
5.5 EPICYCLIC REDUCTION GEAR ASSY (W50TC)	51
5.6 EPICYCLIC REDUCTION GEAR ASSY (W60TC, W70TC, W80TC)	55
5.7 WHEEL HUB ASSY (W50TC)	59
5.8 WHEEL HUB ASSY (W60TC, W70TC, W80TC)	68
